

WHEEL STUD INSTALLER SET



Item #	Inner	Master	UPC	Packaging
W83045	12	48	039564154256	Carded
 Use to install new wheel studs, when theyÕve been damaged, broken, or stripped Works on most automotive and truck wheel studs, domestic and imports The attached bearing reduces friction allowing the replacement stud to be easily pulled into the hub Prevent damage to the lug nut or 			 the threads of a new wheel stud Use with impact wrench or ratchet, to pull the new stud securely in place Size 9/16 in. (14 mm) in diameter, works on most all automotive and half-ton pickup truck wheel studs Size: 7/8 in. (22 mm) in diameter, work on truck wheel studs 	

performancetool.com

P.O. Box 88259 Tukwila, WA. 98138 1-800-426-1262 (USA & Canada) 1-800-352-9185 (Fax)

WHEEL STUD INSTALLER Gar & Truck INSTALLATEUR DE GOUJON DE ROUE Voltere et Caniaa INSTALADOR DE ESPÁRRAGOS DE RUEDA