



Purchase Date: ___ / ___ / ___ Order/Customer Reference Number: _____

Thank you for choosing Sunnydaze Decor. We stand behind our brand and the quality of the items we sell. Replacement parts or products will be sent at our discretion within the 1-year warranty period. Proof of purchase, with the date of purchase as well as photos of the merchandise defect, must be provided. Photos are used to determine the cause of defects and for future quality control. Register your warranty at <https://tiny.cc/SunnydazeWarranty>. If you have any questions, comments or concerns, feel free to contact us by phone at 833-982-1977, by email: customerservice@sunnydazedecor.com, or via our contact us page at <https://tiny.cc/SunnydazeContact>

RATTAN WICKER PLANTER WITH CLEAR PLASTIC LINER

Read all information carefully before using this product. Save this document for future reference.

! **IMPORTANT:** The plastic liner is preattached inside the planter. The liner is not replaceable and should not be removed or punctured. Removing or puncturing the liner will automatically void the product warranty.



USE & CARE

FILLING: Only use lightweight potting soil. Take care not to puncture the built-in plastic liner.

WATERING: Take extra care when watering. Over-watering may damage plants and may also damage surfaces if the inner liner was punctured while filling.

INDOOR USE ONLY: For indoor use only. Using this item outdoors will automatically void the product warranty.

MOVING: Always lift the planter from the bottom when moving it, never drag or slide it as doing so will damage the wicker rattan. Slowly and gently set the planter down to prevent breakage.

CLEANING THE WICKER: Brush or vacuum to remove loose dust, dirt and debris.

Mix 1/4 cup of mild soap with 1 gallon of warm water. Use a soft-bristled brush to gently scrub the dirt and grime from the wicker.

Thoroughly rinse, ensuring all soap residue has been removed.

If possible, place the planter on a towel in direct sunlight to dry. Ensure the planter is thoroughly dry before storing or refilling.

STORAGE: Store in a dry, indoor location. Cover to prevent dust and debris build-up.

Any modification to the product or failure to follow recommended care will void the product warranty.

! WARNING!

Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the improper use, inadequate maintenance, or neglect of this product.

