



A Pin has been installed to secure the door closed during shipping. From the top of the cabinet, remove the Pin by pulling it up and out of the hole. Discard the Pin.

A Plug has been provided to insert into the bottom of the Pin hole as shown. Insert the Plug into the hole AFTER the cabinet set-up is complete.

Follow the SAFETY TIPS in the Cabinet Instructions.