


KENMARE 4-PIECE RESIN WICKER & ACACIA PATIO FURNITURE SET GF-677



! HELPFUL HINT















Sunnydaze Decor advises reading this manual fully, and assembling the furniture set soon after purchase. Check that all parts are accounted for and familiarize yourself with the assembly before beginning. Save this manual for future reference.

COMPONENTS






Inspect packaging to ensure all parts are accounted for before disposing of packing materials.



 <p>A Loveseat Backrest Qty. 1</p>	 <p>B Loveseat Seat Qty. 1</p>	 <p>C Right Arm Panel Qty. 3</p>	 <p>D Left Arm Panel Qty. 3</p>	 <p>E Chair Backrest Qty. 2</p>
 <p>F Chair Seat Qty. 2</p>	 <p>G Table End Panel Qty. 2</p>	 <p>H Table Side Panel Qty. 2</p>	 <p>J Loveseat Cushion Qty. 1</p>	 <p>Q Chair Cushion Qty. 2</p>
 <p>X Back Pillow Qty. 4</p>	 <p>W Tabletop Qty. 1</p>	 <p>Z Throw Pillow Qty. 1</p>	<p>Tip: Always fully insert the hex key inside designated notch of the bolt.</p>  <p>If the hex key is not fully inside the notch, the hex key could slip out, causing damage to the bolt head. Repeated hex key slipping will cause the notch to become rounded, making it difficult or impossible to tighten the bolt with the hex key.</p>	

HARDWARE

WARNING! CHOKING HAZARD — Small parts. Keep children away during assembly.


 <p>1 M6x40mm Bolt Qty. 28</p>	 <p>2 M6x30mm Bolt Qty. 12</p>	 <p>3 M6x100mm Bolt Qty. 6</p>	 <p>4 M6 Washer Qty. 46</p>	 <p>5 M4 Cap Qty. 6</p>	 <p>6 M4 Hex Key Qty. 2</p>
--	--	--	---	---	---

HELPFUL HINT: Do not tighten hardware until all components have been loosely assembled. If the hardware is tightened too soon, mounting holes may not align, and parts may not easily fit together.

LOVESEAT ASSEMBLY

STEP 1


- A: 1
- B: 1
- 1: 2
- 4: 2



Do not fully tighten hardware until after Step 3 is complete.

STEP 2


- C: 1
- 1: 4
- 3: 1
- 4: 5
- 5: 1



Do not fully tighten hardware until after Step 3 is complete.

STEP 3


- D: 1
- 1: 4
- 3: 1
- 4: 5
- 5: 1



Do not fully tighten hardware until all components in this step have been connected.

STEP 4


- J: 1
- X: 2
- Z: 1



INDIVIDUAL CHAIR ASSEMBLY

STEP 5


- E: 1
- F: 1
- 1: 1
- 4: 1



Do not fully tighten hardware until after Step 7 is complete.

STEP 6


- C: 1
- 1: 4
- 3: 1
- 4: 5
- 5: 1



Do not fully tighten hardware until after Step 7 is complete.

STEP 7

- D: 1
- 1: 4
- 3: 1
- 4: 1
- 5: 1



Do not fully tighten hardware until all components in this step have been connected.

STEP 8

- Q: 1
- X: 1





TABLE ASSEMBLY

STEP 9


- G: 1
- H: 2
- 2: 2
- 4: 2



Do not fully tighten hardware until after Step 11 is complete.

STEP 10


- G: 1
- 2: 2
- 4: 2




Do not fully tighten hardware until after Step 11 is complete.

STEP 11

- W: 1
- 2: 8
- 4: 8



Do not fully tighten hardware until all components in this step have been connected.



Care & Maintenance

*Resin wicker furniture requires minimum maintenance.
Follow these basic tips to prolong the life of your resin wicker furniture.*

Protect: Storing cushions indoors when the furniture is not in use is highly recommended.

Cover: Covering the furniture with a breathable cover when it's not being used will help protect it from the harmful effects of sunlight, dust build-up, and collecting debris.

Sun Exposure: All materials and fabrics will eventually fade and degrade from sun exposure. Maintain cushion color and integrity by covering the furniture or storing cushions indoors when not in use.

Winter Care & Storage: Move the furniture to a cool, dry location to preserve the quality and to protect the frame from rusting. Covering furniture while in storage is recommended to help prevent dust build-up. Ensure cushions are stored in a location safe from critters and are completely dry before storing.

Cleaning

Regular cleaning keeps your resin wicker furniture looking stunning for many Sunnydaze to come!

Do not use harsh chemicals or abrasive materials to clean the furniture.



HAND-WASH ONLY



DO NOT USE BLEACH



DO NOT USE A PRESSURE WASHER

Cushions/Pillows

- Brush or vacuum loose dirt from the cushions.
- Wipe the cushions down using a soft cloth and cool water. For more stubborn stains, clean with mild soap and cool water, using a soft-bristle brush.

Furniture

- Remove all cushions.
- Brush, vacuum or use a garden hose to remove loose dirt and debris. If using a hose with a spray nozzle, use gentle or medium pressure settings; high-pressure sprayer settings will damage the construction of the furniture and void the product warranty.
- Mix 1/4 cup of soap or mild detergent with 1 gallon of warm water. Using a soft-bristle brush, gently scrub the dirt and grime from the resin wicker.
- Spray with the garden hose or use a bucket of water to rinse all traces of soap residue from the furniture.

Wooden Surfaces

- Use a slightly damp cloth to wipe down wooden surfaces. Dry with a soft, lint-free cloth.

! SAFETY STATEMENTS & WARNINGS !

- Do not exceed the weight capacity of the furniture.
- Do not sit, stand, or climb on the table.
- Inspect hardware often and tighten loose hardware before use.
- Do not put hot items on or near furniture.
- Keep furniture a safe distance from heat sources such as fire pits, patio heaters, and grills.
- Do not allow children to use this product without adult supervision.
- Do not use harsh chemicals or abrasive materials to clean the furniture.

Any modification to the product or failure to follow recommended care will void the product warranty.

! WARNING!

Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.