

# PROPANE FIRE PIT WITH TABLETOP ATTACHMENT USER GUIDE



# **WARNING**

INSTALLER: Leave this manual with the appliance. CONSUMER: Retain this manual for future reference.

# **WARNINGS**

# **WARNING**

#### FOR OUTDOOR USE ONLY.

Installation and service must be performed by a qualified installer, sevice agency or gas supplier.

# **⚠** WARNING

#### FOR YOUR SAFETY:

If the information in this manual is not followed exactly, a fire or explosion may result causing property damage, personal injurty or loss of life. WHAT TO DO IF YOU SMELL GAS:

- Do NOT try lighting any appliance.
- · Do NOT touch any electrical switch; do NOT use any phone in your building.
- · Immediately call your gas supplier from a neighbor's phone.
- · Follow the gas supplier's instructions.
- · If you cannot reach your gas supplier, call the fire department.

Do NOT use for cooking.

# **WARNING**

### **FOR YOUR SAFETY:**

Improper installation, adjustment, alteration, service or maintenance can cause injury or property damage.

Read the installation, operation and maintenance instructions thoroughly before installing or servicing this equipment.

### **⚠** DANGER

Do NOT leave this appliance unattended while it is in operation.

# **DANGER**

#### FIRE OR EXPLOSION HAZARD

If you smell gas:

- · Shut off gas to appliance.
- · Extinguish any open flame.
- · If odor continues, leave the area immediately.
- · After leaving the area, call your gas supplier or fire department.

Failure to follow these instructions could result in fire or explosion, which could cause property damage, personal injury, or death.

# **WARNING**

#### FOR YOUR SAFETY:

- 1. Do not store or use gasoline, or other flammable vapors and liquids, in the vicinity of this or any other appliance.
- 2. An LP-cylinder not connected for use shall not be stored in the vicinity of this or any other appliance.

### **DANGER**

### CARBON MONOXIDE **HAZARD**

This appliance can produce carbon monoxide which has no odor.



Using it in an enclosed space can kill you. Never use this appliance in an enclosed space such as a camper, tent, car or home.

# **WARNINGS**



Note: If using tabletop accessory with glass surround (sold separtely), follow assembly instructions and warnings found in the user guides accompanying each accessory.

### **WARNING**

- · Read all instructions before using this table.
- · Areas of the tabletop may be too hot to touch. To avoid burns, DO NOT touch hot surfaces until the unit has cooled, unless you are wearing protective gloves.
- · Children and adults should be alerted to the hazards of high surface temperatures and should stay away to avoid injury.
- · Never lean over the propane fire pit when in use.
- · Items placed on tabletop may become hot.
- $\cdot$  Items placed on temperature with low melting points, such as plastics, may become soft and melt.
- · Glass or metal objects placed on tabletop while burner is in operation will get hot and stay hot long after burner is extinguished.
- · Liquids contained in vessels placed on tabletop may become hot. Avoid prolonged contact between tabletop and containers holding liquids.
- $\cdot$  Do not place electronics on tabletop while burner is in operation.
- · Surface may become hot when in the sun.

# **TABLE OF CONTENTS**

Warnings	2
Parts List	4
Assembly Instructions	6
Care & Maintenance1	0
Limited Warranty	1

# **PARTS LIST**

Compare all parts with the Package Contents and Hardware Included lists. If any part appears missing or damaged, DO NOT assemble or use this product. DO NOT RETURN TO PLACE OF PURCHASE. For assistance, contact Customer Service at 1-888-473-1088.

Please have your owner's manual and model number available for reference.

Note: The model number is printed on the rating label which can be found on the inside of the door panel.


Part	Description Quan	tity
6005454	Tabletop	1
7004136*	Hardware Pack	1
	(Following included in Hardware Pack)	
6005996	4mm Hex Key	1
6005884	M6x20 Stainless Screw	7

<sup>\*</sup>This part will not be included if the tabletop and base were packaged in the same box

4 TIKI Brand | Propane Fire Pit Tabletop User Guide


# **PARTS LIST**

Note: Items not shown to actual scale or size



▲ WARNING: CHOKING HAZARD — Small parts. Not for children under 3 years.

Hardware Pack\*



\*This part will not be included if the tabletop and base were packaged in the same box

# **ASSEMBLY INSTRUCTIONS**

# **WARNING**

FAILURE TO POSITION THE PARTS IN ACCORDANCE WITH THESE DIAGRAMS OR FAILURE TO USE ONLY PARTS SPECIFICALLY APPROVED WITH THIS APPLIANCE MAY RESULT IN PROPERTY DAMAGE OR PERSONAL INJURY.

### **Assembly Tips:**

- · Choose an area where you will assemble the product. To protect components, choose a smooth surface that is free of cracks or openings.
- · Spread out all parts.
- · Loosely tighten all hardware connections first. Fully tighten hardware in the steps instructed as adjustment may be necessary prior to fully tightening. Be careful not to over-tighten. Over-tightening hardware could damage or strip threads.
- · For best results, complete each step in the order as shown in this manual.

# **CAUTION**

To avoid scratches or other damage to the unit, choose a smooth surface for assembling the unit.


# **CAUTION**

Before installing or removing the tabletop, make sure the fire pit is off and LP gas tank valve is closed. Wait 1 hour before removing the tabletop assembly.

- · The Tabletop Attachment should only be used with the TIKI® Brand Propane Fire Pit only.
- $\cdot$  Refer to User Guide for the Propane Fire Pit for additional instructions.

# STEP 1


Remove the (7) screws that are not in keyhole slots from the top of the Propane Fire Pit. Note: DO NOT remove screws circled in red.



# **ASSEMBLY INSTRUCTIONS**

### STEP 2

Place tabletop (6005454) on top of propane fire pit. Align oval slots with the hole locations of the removed screws, making sure alignment mark on the tabletop aligns with the mark on the base unit. Also align the circular slots with the 3 screws still remaining in the top of the fire pit that were not removed.




# **ASSEMBLY INSTRUCTIONS**

# **WARNING**

NEVER place basin cover on propane fire pit while in use.

NEVER place basin cover on propane fire pit while the appliance is still hot.

When the Propane Fire Pit is not in use, the Basin Cover (sold separately) should be placed in the center of the tabletop. When the Fire Pit is in use, the Basin Cover may be stored under the unit. Place cover onto wire rack provided as shown taking care to not strike the propane system.



# **CARE & MAINTENANCE**

#### Before Each Use:

- · Keep propane fire pit area clear and free from any combustible materials, gasoline and other flammable vapors and liquids.
- · Do NOT obstruct the flow of the combustion of LP gas and/or the ventilation air.
- · Keep the ventilation openings of the LP gas tank area free and clear from debris.
- · Visually check the burner flames to make sure your appliance is working properly.
- · Check all gas connections for leaks.
- · Check components for any signs of damage or rust.
- · Check for obstructions of airflow to the burner. Spiders, insects and webs can clog the burner/venturi tube. A clogged burner/venturi tube can lead to a fire.
- · If damage to any component is detected, do NOT operate until repairs are completed.

#### **Before Storing:**

- · Clean all surfaces
- · If storing the propane fire pit indoors, cover the appliance and store in a cool dry location away from children and pets.
- · If storing the appliance outdoors, cover fire pit with a weather cover for protection from the elements, sold separately.
- · Store appliance upright in an area sheltered from direct contact with inclement weather such as rain, sleet, hail, snow, dust, debris and high winds.
- · Place the protective cap on the LP tank outlet and store the tank outdoors in a well-ventilated area out of direct sunlight.

### **CAUTION**

All cleaning and maintenance should be done when propane fire pit is cool and with the fuel tank safely disconnected.

Do NOT clean any components of this appliance in a self-cleaning oven. The extreme heat will damage the finish.

Do NOT enlarge valve orifices or burner ports when cleaning the valves or burners.

# **WARNING**

All cleaning should be done when the appliance is cool and with the fuel tank disconnected per instructions found in 'Disconnecting LP Gas Tank' (see User Guide for the Propane Fire Pit).

### 10 TIKI Brand | Propane Fire Pit Tabletop User Guide

# LIMITED WARRANTY

Visit TIKIBrand.com/customer-service/our-guarantee or contact us at 1-888-473-1088 for more information.

For information on patents go to TIKIBrand.com/patents



This product and combustion products emitted when this product is burning can expose you to chemicals including carbon monoxide which is known to the State of California to cause birth defects or other reproductive harm, and lead which is known to the State of California to cause Cancer and birth defects or other reproductive harm. For more information go to www.P65warnings.ca.gov.

#### Specifications:

- · Certifications: ANS Z21.97 \* CSA 2.41-2017
- · Normal Hourly Input Rating: 40,000 BTU/hr. (11.7kW)
- · Fuel: Liquid Propane Gas
- · Tank Size: Nominal 20 lb.
- · Manifold Pressure: 11.0 in W.C.
- · Safety Features: 100% Burner shut-off / Thermocouple / Tip Angle Switch
- · Manufacturer: Lamplight Farms Incorporated
- · Made In: China

Questions, problems, missing part? Call 1-888-473-1088.

TIKIBrand.com

Retain this manual for future use.



**TIKIBRAND.COM** 

4002326 REV3

©2024 Lamplight Farms Incorporated