

# **TEAMSON** HOME


PEAKTOP
3 PIECE PATIO WICKER BISTRO SET


PT-OF0006 PT-OF0006-UK TIME SAVER!











<sup>\*\*</sup> Got questions? Please have your product code (on the first page of this instruction, e.g. PT-OF0006) and the order number ready, give us a call or email us through our customer care support! We are always ready to assist you!

# **企 TEAMSON** HOME



## Warranty sign up

# www.teamsonhome.com

Serving you well gives us great joy!

**USA** .... +1(800)935-3959

Mon - Fri 10:00am ~ 2:00pm EST ⊠ support@teamson.com

**EU** ····· +44(0)1952-916-050

Mon - Thu 9:00am ~ 5:00pm GMT Friday 9:00am ~ 4:00pm GMT

ASIA··· 深圳办公室:

+86(0755)8885-3558.分机号331


Mon - Sat 9:00am ~ 5:00pm GMT+8

⋈ sales\_ec@teamson.com

台北辦公室:


+886(2)2556-6268


# Exploded Drawing





### **Product Parts**







#### ▲ Care Instructions


Dust surface with a dry soft cloth.

Do not use window cleaners or cleaning abrasives as they will scratch the surface and could damage the protective coating



Small parts and sharp edges may be present prior to assembly.

# Step 1



## Step 2

