

Order/Customer Reference Number:


Thank you for choosing Sunnydaze Decor. We stand behind our brand and the quality of the items we sell. Replacement parts or products can be requested with the 1-year warranty period. Proof of purchase, with the date of purchase as well as photos of the merchandise defect, must be provided. Photos are used to determine the cause of defects and for future quality control. Register your warranty at https://tiny.cc/SunnydazeWarranty


If you have any questions, comments or concerns, feel free to contact us by phone at 833-982-1977, by email: customerservice@sunnydazedecor.com, or via our contact us page at https://tiny.cc/SunnydazeContact

INDOOR/OUTDOOR ALL-WEATHER FOLDABLE BAR TABLE

TLA-828

Read all assembly and care instructions carefully before using this product. Save this manual for future reference. Assemble components on a soft, clean surface to avoid damaging the finish.





Parts	QTY.
Tabletop	1
Metal Tube	1
Weight-Mounted Threaded Rod	1
Leg Base	1
M10 Nut (installed on threaded rod)	2
M10 Lock Nut (installed on threaded rod)	1
Washer (installed on threaded rod)	1

TOOLS REQUIRED (not included) 17mm Combination Wrench

WARNING

CHOKING HAZARD — This item contains small parts that can be swallowed. Keep children and pets away during assembly.

Tabletop folds down for easy storage!



Weight Capacity

ASSEMBLY

Read carefully and understand assembly before beginning.

Fasten hardware equally and tightly - failure to do so may cause table to crack and break.





STEP 1

Lay the Tabletop face-down on a smooth, clean surface. Remove the pin. Press the lever on the folding mechanism and flip it open.

Remove <u>one</u> M10 Nut from the long side of the Weight-Mounted Threaded Rod. Place the nut on the inside of the folding mechanism, as shown in the 1st picture.

Screw the long threaded rod into the nut until it is flush with the nut in the folding mechanism. Tighten the outside nut, as shown in 2nd picture.



STEP 2

Close the folding mechanism and finish tightening the M10 Nut.

Remove the M10 Lock Nut and Washer from the short side of the Weight-Mounted Threaded Rod.

Slide the Metal Tube over the Weight-Mounted Threaded Rod, ensuring the groove in the tube is aligned with the notch on the folding mechanism.

Place the leg base onto the metal tube, ensuring the groove and notch align, as shown.






STEP 3

Ensure components are tightly fitted, with grooves and notches fully aligned.

On the underside of the leg base, place the Washer on the Threaded Rod. With the flat side down, securely fasten the M10 Lock Nut onto the treaded rod.



IMPORTANT: Lock nuts must be installed with the nylon insert on the outside. Tools must be used to fully tighten lock nuts, failure to properly tighten the lock nuts may result in product malfunction or personal injury.





STEP 4

Secure the tabletop by inserting the pin into the folding mechanism, as shown.

Sunnydaze Decor



SunnydazeDecor.com

05/2023 Page 2 / 3

Care & Maintenance

SAFE USE: Never sit or stand on the table.

INSPECT: Periodically check assembly points and tighten hardware as necessary.

COVER: When not in use, covering the table with a breathable cover will help protect it from the harmful effects of sunlight, dust build-up, and collecting debris.

WINTER CARE & STORAGE: Protect this item from inclement weather, especially ice and snow. Move the table to a cool, dry indoor location. Cover the table while in storage to help prevent dust build-up.

Cleaning

Do not use harsh chemicals or abrasive materials to clean the table.

X DO NOT USE BLEACH

ODO NOT USE A PRESSURE WASHER

Mix mild soap with warm water and wash the table using a soft cloth. Thoroughly rinse soap residue off the table. Dry with a soft, lint-free cloth.

🛕 SAFETY STATEMENTS & WARNINGS 🛕

- Do not exceed the weight capacity of the furniture.
- · Do not sit or stand on the table.
- Inspect hardware often, tighten loose hardware before use.
- Do not put hot items on or near furniture.
- Do not allow children to use this product without adult supervision.
- Do not use harsh chemicals or abrasive materials to clean the furniture.
- Do not use a pressure washer to clean the furniture.

Any modification to the product or failure to follow recommended care will void the product warranty.

If you experience issues with assembly or the product was damaged during shipping, please contact our customer service team through one of the methods mentioned at the top of page 1.

Please have the item number and order information ready to expedite response time.

≜WARNING!

Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.

Sunnydaze Decor •••• Sunnydaze Decor.com