

- Prominent decoy button can be pushed by child, with no effect
- Flexible surface hides functional buttons in plain sight
- Easy installation with no drilling required
- Fits on both cabinet knobs and handle pulls
- Hangs conveniently out of the way for times when it's not needed
- Adjusts to fit cabinets with hardware from 3" up to 8" apart



Package Type	Units Per	Height (inches)	Width (inches)	Depth (inches)	Weight (lbs)	Cubic Feet	UPC
Each	1	7.63	3.63	1.13	0.23	0.02	0884392600693
Inner Carton	4	4.0	2.63	11.63	0.94	0.07	10884392600690
Master Carton	24	8.9	8.3	12.2	5.61	0.52	20884392600697



• Fits on both cabinet knobs and handle pulls



• Easy installation with no drilling required



• Adjusts to fit cabinets with hardware from 3" up to 8" apart

