INSTRUCTION MANUAL




! CARE & MAINTENANCE

Do not overtighten screws. (Insert all screws before tighten screws.)


- Please do not exceed the weight limitations of this item.
- Do not stand on or use any part of this item as a step ladder
- Firmly secure all bolts, screws and nuts before use.
- Reconfirm that all bolts, screws, and nuts are secure every 90 days.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.




HARDWARE





PARTS












PRODUCT ASSEMBLY - OVERALL VIEW

Look at following overall view of this stool and exact position of each parts to be assembled.




PRODUCT ASSEMBLY



Attach Part B & C Stool Legs to Part A Saddle with 8 pcs of Hardware #1 Bolt.

Do not tighten screws too much at this step.




PRODUCT ASSEMBLY

2

Remove the cap from the safety pin before you fix the **Part D Short Rail** to **Part B & C Stool Legs**.


Attach Part D Short Rail to Part C and Part B Stool Legs with 4 pcs of Hardware #1 Bolt. Do not tighten screws too much at this step.



3

Attach Part E Long Rail to the combined Legs (Part B+C) as below with 4 pcs of Hardware #1 Bolts.

Remove the cap from the safety pin before you fix the Long Part E Long Rail to stool legs.





Tighten all the bolts and finish the assembly.



CLEANING TIPS

REGULAR CLEAN: Use a mixture of warm water and mild soap. Gently scrub the surface with a soft bristle brush to remove any dirt or stains.

QUICK CLEAN: You can simply wipe down the furniture with a damp cloth.

Regular cleaning not only preserves the aesthetic appeal of your furniture, but also helps extend its lifespan.