



## GRIP PLUS PENCIL



- Grip Plus Pencils come equipped with 0.7mm (B) standard lead.
1. Remove the eraser holder (2) from the barrel (1) by firmly pulling the eraser holder (2) off gently.
  2. Insert new Faber-Castell 0.7mm leads (3) into the back end of the barrel (1). Add no more than 5 leads. If more leads are used this may cause a jam.
  3. Return the eraser holder (2) to the barrel (1) by firmly pushing the eraser (2) back into place.
  4. To advance the lead, push down on the eraser holder (2) and begin writing.
  5. To retract the lead, push down on the eraser holder (2). Push the lead back into the front piece (1) while the eraser holder (2) is held in place.

REFILLS Eraser: #131598 on Blister Card  
Lead: **0.7mm** (B) Standard 2pk on Blistercard #122298  
Other degrees of lead hardness also available (2B, HB, H, 2H)