










ITEM: 6750-80315-06 End Table
6750-80315-40 End Table




Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.



HARDWARE PACK

NO.	DRAWING	DESCRIPTION	SIZE	Q'TY
A		Bolt	5/16"	8PCS
B		Lock Washer	5/16"	8PCS
C		Flat Washer	5/16"	8PCS
D		Allen Wrench	73*29*5mm	1PC
E		Bolt	1/4"	4PCS
F		Lock Washer	1/4"	4PCS
G		Flat Washer	1/4"	4PCS
H		Allen Wrench	69*27.2*4mm	1PC
I		Anti-Tip Kit		1PC

PART LIST

NO.	DRAWING	DESCRIPTION	Q'TY
①		Leg	4PCS
②		Top	1PC
③		Bottom Panel	1PC

Note: Please take out the drawer before assembly and put it back after assembly.



Step 1: Attach three of the legs (1) to top (2), well insert bolts (A), lock washers (B) and flat washers (C). Please do not fully tighten bolts. (See Diagram 1)


Step 2: Attach the bottom shelf (3) to the legs (1) with bolts (E), lock washers (F) and flat washers (G), do not fully tighten bolts (E) at this step too. (See Diagram 2)

Note: Anti-tip kit restraint is provided. Please follow the instructions enclosed with the pack.

ASSEMBLY INSTRUCTION

ITEM: 6750-80315-06 End Table
6750-80315-40 End Table

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process.





Step 3: Assemble the rest of the leg to the top and bottom shelf (Refer to Diagram 3).

Step 4: Now tighten bolts (A) with allen wrench (D), and bolts (E) with allen wrench (H).

Tipping Restraint

Anti-tip kit is included for use. We recommend installing for safety reason



Adjust Leveler if needed to level table on uneven floor.

STEP 5