


ITEM NAME/NOM D'ITEM: ASHLEY DINING CHAIR  
ITEM # /NO.ITEM : 101846


## PARTS LIST/LISTE DES PIÈCES

(1)



x 1


(2)




x 4

## ASSEMBLY INSTRUCTIONS / INSTRUCTIONS D'ASSEMBLAGE

I



II



For missing parts or damaged parts, please call:

USA: 1-866-798-6663

Canada: 514-382-6661