







ASSEMBLY INSTRUCTION

Item#: 5300-10482 Writing Desk

**** Please make sure you have all parts indicated below prior to assembly.
It's better to assemble this desk with help of two or more persons.**

NO.	HARDWARE LIST		Q'TY
A		ALLEN WRENCH	1
B		BOLT	8
C		LOCK WASHER	8
D		FLAT WASHER	8



Assembly Steps:

1. Place the writing desk upside down on a soft surface to prevent it from scratching.
2. Attach one leg as labeled to top, using bolt (B), lock washer (C), flat washer (D), secure by turning with allen wrench (A) in a clockwise direction tightly.
3. Attach other three legs in same way as step 2.
4. Turn the writing desk upright.

Cleaning Instruction: Clean finished parts with a damp cloth using a mild dishwashing liquid and water solution. Polish the finish with soft cloth and an industry recognized furniture polish.