

Thank you for choosing Sunnydaze Decor. We stand behind our brand and the quality of the items we sell. Replacement parts or products can be requested with the 1-year warranty period. Proof of purchase must be provided. This includes the date of the purchase as well as photos of the product defect. Photos are used to determine the cause of the defect and to provide future quality control. The request will be reviewed, and replacement pieces will be sent at our discretion. For warranty information, visit <https://tiny.cc/SunnydazeWarranty>

If you have any questions, comments or concerns, feel free to contact us by phone at 833-982-1977, by email:

customerservice@sunnydazedecor.com, or via our contact us page at <https://tiny.cc/SunnydazeContact>



3-Tier Burning Bowls Water and Fire Fountain




Please read instructions below before first-time use:

- Do not tip fountain as fuel can spill out and cause fire or serious injury.
- For outdoor use only.
- Fuel not included. Use torch fuel or bio ethanol fuel. Use of any other fuel will void your warranty.
- Failure to follow warnings and instructions may result in serious injury or destruction of property.
- Keep out of reach of children or pets.
- Do not leave flame unattended.
- Do not move fountain while burning. Hot while in use.
- To prevent burns and other injuries, snuff flame and allow to cool completely before handling.
- Refill flammable liquid before use, and only refill when flame area is cold. Wait at least 30 minutes before refilling or cleaning.
- Keep clothing, hair, and body parts away from flame; may cause serious injury or burns.
- DO NOT place fountain under covered shelter or umbrella, or near other combustibles, such as, but not limited to: wood structures, clothing, or dry vegetation.
- Use in a well-ventilated area.
- Do not spill flame fuel into water portion of fountain as that may cause damage to the fountain, pump, or destruction of property.

Assembly:

1. Pull the end of the hose out of the bottom of the detached bowl. Place the hose inside the large opening in the top of the fountain then lower the detached bowl into place.
2. On the faceplate to the pump, turn the flow to "low". Attach the hose, found inside the fountain, to the top of the pump and set inside the bottom of the fountain.
3. Run the power cord through the notch in the door.
4. Turn the door to lock it in place.



5. Unscrew the lids of the fuel reservoirs and carefully pour fuel into them. Do not get water into fuel reservoirs. Replace the lid and place the fuel reservoirs into the fountain.



Fuel not included.

Use torch fuel or bio ethanol fuel.

Use of any other fuel will void your warranty.

6. Fill bottom basin with water.
7. Light the flames (**lighter not included**).
8. Plug into electrical outlet.

