









ASSEMBLY INSTRUCTION


CHEST

A Chest Body  1pc	B Leg  4pcs	C Bolt Ø1/4"x44mm  8pcs	D Lock Washer Ø1/4"x10mm  8pcs
E Flat Washer Ø1/4"x16mm  8pcs	F Allen Key M4  1pc	G Anti-Tipping  1set	




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.


1 Take off the Leg from Chest Body (A).




2 Attach Leg (B) to the Chest Body (A) using Bolt (C), Lock Washer (D), Flat Washer (E) by Allen Key (F). Turn the Allen Key (F) in the Bolt (C).



- 3** Unscrew and take off knobs from back sides of drawers, then install the knobs to the front side of drawers.



- 4** Remark: There is a tip restraint kit provided on the back of this product. Please refer carefully to the instruction on the tip restraint kit and following instruction picture for installation.



Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.