


INSTRUCTION MANUAL



**29" Wide Faux Shearling Fabric
Accent Chair With Arms**

V1.0

! CARE & MAINTENANCE

- Be careful when assembly, avoid hurting the plating of the surface.
- Clean the chair with lukewarm water, mild detergent & soft cloth.
- Firmly secure all bolts before use, do not use any part of this item as a step ladder.
- Reconfirm that all bolts, screws, and nuts are secure every 90 days.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.
- Do not overtighten screws. (Insert all screws before tighten screws.)

TOOLS REQUIRED



ALLEN WRENCH
(PROVIDED)



300 LBS
CAPACITY



1 PERSON
ASSEMBLY



UP TO 15 MIN.
ASSEMBLY

HARDWARE

1

BOLT
M6 x 20mm



12PCS

2

ALLEN WRENCH
M6




1 PC

PARTS

A

CHAIR BODY



1 PC

B

LEG

with adjustable feet leveler




4 PCS

adjustable feet leveler




PACKING

Open the zipper take out legs .



PRODUCT ASSEMBLY-OVERALL VIEW


Look at following overall view of this chair and learn the exact position of each parts to be assembled.



PRODUCT ASSEMBLY

1

Attach 4pcs of Part B Legs to Part A Body with 12pcs of Hardware 1 Bolt.



2

Adjust the feet levelers for perfect balance.

