

Purchase Date: / /	Order/Customer Reference Number	ï.
--------------------	---------------------------------	----

Thank you for choosing Sunnydaze Decor. We stand behind our brand and the quality of the items we sell. Replacement parts or products will be sent at our discretion within the 1-year warranty period. Proof of purchase, with the date of purchase as well as photos of the merchandise defect, must be provided. Photos are used to determine the cause of defects and for future quality control. Register your warranty at https://tiny.cc/SunnydazeWarranty

If you have any questions, comments or concerns, feel free to contact us by phone at 833-982-1977, by email: customerservice@sunnydazedecor.com, or via our contact us page at https://tiny.cc/SunnydazeContact

GENERAL CARE GUIDE FOR CARIBBEAN HAMMOCK CHAIRS

Save this guide for future reference.

USE & CARE

- ROPES: Even with normal use, all rope-style hammock chairs will stretch. Keep this in mind when hanging this hammock chair.
- SAFE USE: Do not swing, bounce, jump, twist, or make other excessive movements while using this chair. Misuse of the hammock chair, such as using it like a swing or exceeding the weight limit, can cause the ropes to stretch or break.
- SUN EXPOSURE: All fabrics will eventually fade and degrade from sun exposure. The less direct sunlight the hammock chair is exposed to, the longer the life of the ropes will be.
- CHILDREN: Supervise children at all times while using this product. Do not allow children or pets to play in the hammock chair. Excessive swinging or rough play may damage the hammock chair and could cause injury.
- **INSPECT:** Before each use, inspect the ropes and spreader bar for wear or weakness.
- **CLEANING:** Clean when soiling or staining is present, and before storage.
- STORAGE: Store indoors, in a dry location during inclement weather, winter, and when it will not be used for an extended time. Ensure it is completely dry before storing to prevent mold and mildew growth.

CLEANING

HAND-WASH ONLY 🗡 DO NOT USE BLEACH OR FABRIC SOFTENERS

LAY FLAT TO DRY

⋈ DO NOT IRON

Hand-wash in a bathtub or kiddie pool using mild soap or detergent and a soft-bristled scrub brush. Soaking may be required for heavily soiled ropes. Keep the wooden spreader bars and galvanized O-rings out of the water as much as possible.

Rinse away all soap residue and air-dry on a flat surface to prevent the ropes from stretching. The ropes may shrink slightly while drying, but will stretch back out with use.

SAFETY STATEMENTS & WARNINGS 1

- Before each use, inspect your hammock chair for wear or weakness. Do not use if the ropes are frayed or fabric is torn.
- Excessive swinging and other rough play may result in serious injuries.
- Small children should not use the hammock chair unsupervised.
- Pets should not be allowed into hammock chairs as it may result in injury or damage the product.
- Do not exceed the recommended weight capacity of the hammock.
- Never until the ropes.

Any modification to the product or failure to follow recommended care will void the product warranty.

⚠WARNING!

Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.

SunnydazeDecor.com Sunnydaze Decor