



Tent Canoe and Tumbler too!


ELR-12915
ELR-12915F-CT
ELR-12915F-ET



OPTION 1



OPTION 2





EASY
FÁCIL
FACILE

HARD
DIFÍCIL
DIFFICILE


IMPORTANT: READ CAREFULLY RETAIN FOR FUTURE REFERENCE
IMPORTANTE: LEA DETENIDAMENTE PARA FUTURAS REFERENCIAS
IMPORTANT : LIRE ATTENTIVEMENT CONSERVER POUR RÉFÉRENCE FUTURE

A


1x




OPTION 1




1




2




3




OPTION 2



1



2



3

⚠ WARNING:

▲ Adult supervision recommended.

⚠ ADVERTENCIA:

▲ Se recomienda la supervisión de un adulto.

⚠ AVERTISSEMENT:

▲ La supervision par un adulte est recommandée.

CLEANING:

Use a clean, damp cloth or sponge with mild soap, non-bleach detergent or general purpose cleaner.

LIMPIEZA:

Use un paño limpio y húmedo o una esponja con jabón suave, detergente sin lejía o un limpiador de uso general.

NETTOYAGE:

Utilisez un chiffon ou une éponge propre et humide avec un savon doux, un détergent sans javellisant ou un nettoyant tout usage.