leakSMART® PRO

Sensor 2.0

Installation and Operation Manual

Wireless, Waterproof & Reusable.

Connect. Protect. Trust.®

ZigBee® Certified Product — works with nest — wink — WORKS WITH iris by Lowe's

---

leakSMART® Sensors provide an audible water detection alarm even without connection to your smart home system hub — but pairing means the system will signal your leakSMART® Valve to automatically shut off your water and send you instant notifications, preventing water damage within seconds.

> **CAUTION:** Read installation instructions BEFORE installing batteries in your leakSMART® Sensor.

- Install 3 AAA alkaline batteries (provided), and the sensor's blue lights will blink quickly.

- Use your smart device to add the sensor to your smart home system app. (You can also manually search for leakSMART® devices in your system's app.)
  - Put your smart home hub in pairing mode, then press the black button (found inside the battery compartment) once.
  - When pairing is successful, the sensor's light will blink slowly five times, and you'll hear 3 quick beeps.
  - Replace battery door.

- Simply place the leakSMART® Sensor anywhere you need to detect moisture.
  - Sensors must be placed on the floor, completely flat, with the leakSMART® Sensor logo facing the ceiling.
  - We recommend placing sensors near appliances and plumbing fixtures.
  - Our waterproof sensors are designed to fit into tight spaces, without shifting or sliding, so it's easy to monitor any area.

- To reset the sensor, remove the battery door, install batteries, press and hold the black button for 15 seconds, then let go. Then power cycle the sensor by removing and reinstalling a battery. Upon reinstallation of the battery, the sensor should chirp and the **Blue** LED light will flash 5 times every second. This indicates it's properly reset and ready to join the system.

  Note: You can remove the sensor from the leakSMART® system and app by resetting it.

---

leakSMART® Sensor Operation

Status	Blue Light	Audible Alarm	Notes
x3 Insert batteries	3 seconds steady	Brief chirp as battery hits metal contacts	
Ready to pair	Fast blinking; will remain in this state and repeat blinking pattern for two minutes	Silent	Put your Smart Home Hub in pairing mode then press the black button once
Pairing successful	Blue light blinks slowly five times	3 Quick beeps	
:30s Working and connected	Blue light blinks once every 60 seconds	Silent	
Water detected	Blue light blinks twice per second (no pause) until out of alarm condition	Five quick beeps; pause; repeat until out of alarm condition	When water is detected, the leakSMART™ Valve will automatically shut off in less than 10 seconds; you will also receive notification on your mobile device
Battery low	Blue light flashes twice per 60 seconds	Chirp every 5 minutes	Low battery notification will be sent to smart device

To purchase additional leakSMART® Sensors or other leakSMART® system accessories, visit www.leaksmart.com

Customer Service: 855-532-5768
customer-service@leaksmart.com

Tech Support: 855-532-5457
techsupport@leaksmart.com

8850600