



Step 4 Parts list



NO.	PART NAME
1	Index
2	Screw
3	Handle
4	Trim cap
5	Cartridge lock nut
6	Cartridge
7	O-ring
8	Copper tube
9	Screw
10	O-ring
11	Connector
12	Screen
13	Body
14	Aerator washer
15	Aerator core
16	Aerator collar
17	Base
18	O-ring
19	Screw
20	Rubber washer
21	Clamp
22	Lock nut
23	Screw
24	Allen key
25	Flexible hose
26	Spring water heater




SINGLE HANDLE LAVATORY FAUCET



ASME A112.18.1/CSA B125.1


RECOMMENDED TOOLS




WARNING:
Please keep the tool for future use!

Attention:
for easy installation, you will need:
1. To read all the installation instruction completely before beginning.
2. To read all the warning, attention and maintenance information.
3. To purchase the proper supply lines.


The tools might be applied to the following places:



Step 1 Faucet installation



1. Assemble the 2 flexible hose and screw to the faucet by hand.
2. Put the faucet into the installation hole of the basin. Make sure o-ring be on the base of faucet. Assemble rubber washer #20 and clamp #21 to screw. Then assemble lock nut #22 by basin wrench to screw to fix the faucet.



3. Connect the flexible hose to water supply valve (not included), and tighten it with adjustable wrench.


DON'T OVER TIGHTEN!

Caution: make sure connect the hot and cold flexible hoses to supply valves correctly.

Warning:

The supply valves are not included, please purchase them in plumb shop.

Step 2 Checking and testing



1. Remove the aerator by hand. Turn the faucet handle all the way on, turn on hot and cold water supply and flush water lines for one minute. Reinstall aerator by hand.
2. Check all connections at arrows for leaks, re-tighten it if necessary. **BUT DON'T OVERTIGHTEN!**

Step 3 Cleaning and care


Daily cleaning and care are required in order to keep the product shining and properly working.

- 1 Clean it with water and dry it with soft cloth.
- 2 Clean the product with gentle liquid or glass cleaner.
- 3 Don't use acid cleaner.
- 4 Don't clean with abrasive material, abrasive paper or knife.



ANZZI VESSEL SINK FAUCET

VESSEL SINK FILLER



L-AZ102
VALOR SERIES