


INSTRUCTION MANUAL



Twin 15' * 9'
Rectangular Market Umbrella
SKU: OS3004

! CARE & MAINTENANCE

- △ Clean with lukewarm water, mild detergent & Sponge.
- △ Wipe down the pole with damp cloth.
- △ Store in a location when not in use.


! SAFETY PRECAUTIONS

- △ Store the umbrella in windy or stormy weather.
- △ Be aware that some parts are heavy and have sharp edges.
- △ Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- △ Do not allow umbrella to flap in the wind as it may cause damage.
- △ When adjusting umbrella, make sure no person or item is close to umbrella to avoid injury or damage.

PARTS

A

UMBRELLA BODY



1 PC

B

EXTEND POLE



1 PC


PRODUCT ASSEMBLY

1

Check the status of umbrella before your assembly.

Plug part B Extend Pole carefully into part A Umbrella Body.


△ Pay attention that the spring bracket on the end of Extend Pole is fixed into the small hole at the end of part A Umbrella Pole after you hear "KA" sound.



2

Insert part B the Extend Pole into the Umbrella Base or the fixing tube on the Table.


Tighten the bolt to fix the Extend pole.



PRODUCT ASSEMBLY

3

Loose the umbrella cloth belt before you open the umbrella.



4

Turn the crank clockwise to open the umbrella while turn anti-clockwise to close the umbrella.

