


Top-Mount Kitchen Workstation Sink

INSTALLATION INSTRUCTIONS





PRIOR TO INSTALLATION:

- Inspect product to ensure no damages have occurred while in shipping.
- Observe all plumbing and building codes in accordance with your state and local requirements.
- Make sure to purchase the correct cabinet size for your sink.
- All dimensions are nominal! Be sure to measure your vanity and sink prior to installation.
- · Installation with laminate countertop not recommended.
- The step-by-step guidelines in the installation instructions are a general reference. Should there be any discrepancies, Swiss Madison cannot be held liable. It is recommended to install all Swiss Madison products by hiring a licensed professional.
- Read installation and maintenance instructions thoroughly before installing. Be sure to use proper tools and always wear proper personal safety accessories for your protection.

Lifelong Care: Swiss Madison Stainless Steel Sinks are easy to maintain with minimal care. For best results, always rinse with mild soap and wipe after each use. Rub lightly with soft cloth in the direction of the drain on a regular basis. To avoid damage and discoloration to the sink surface never use steel wool, scouring pad or abrasive cleaners.

OUESTIONS OR CONCERNS?


Please contact us:

1-434-623-4766

info@swissmadison.com

INCLUDED PARTS:







SUGGESTED TOOLS & MATERIALS:









Level



Denatured

Alcohol



Tape

Measure



Screwdrivers



Jig Saw/ Hacksaw







Gloves





Pencil

Adhesive

Putty Knife


Scissors

Wrench

Hammer


Position and Trace Template

- · Check the cutout template against the actual sink to ensure a proper sized cutout.
- · Place the cutout template in the desired location on the countertop.
- · Trace the template onto the countertop.
- · Make sure clearance is suitable for back splash, faucet, and plumbing for the sink.




2 Cut Countertop

- \cdot Cut an opening in the countertop by carefully following the traced line from the template.
- · Please use the appropriate saw that best fits your countertop material. Professional should be consulted for cutting countertop.




3 Prepare the Sink

- · Place the sink into the installation hold to verify the fit. Adjust the cutout if necessary.
- · Place the sink upside down and align the bottom edge with waterproof strip.




4 Attach Mounting Clips

· Attach the top-mount clips to the edge of the sink.




5 Install the Sink


- Apply silicone sealant (not included) around the underside and lip of the tank.
- Test run water into sink and checkfor leaks. Carefully lower the sink into the counter.
- Tighten the screws on the top-mount clips evenly untilo the sink is flush with the counter. Do not over-tighten.
- · Wipe excess sealant with a rag.



6 Install Plumbing Fixtures

- · Connect drain trap to drain, and water supply connections to faucet according to manufacturer's instruction.
- · Test run water into sink and checkfor leaks.





*ACCESSORIES:

- 1. 4.5" Slotted Stainless Steel Drain
- 2. 16.75" x 12" Cutting Board
- 3. 17" x 8" Stainless Steel Colander
- 4. Roll Up Sink Grid
- 5. 9" x 16.75" 3-Bowl Serving Board
- 6. Mixing Bowl and Colander Bowl Set
- 7. 17" x 17" Flatform with Colander and Mixing Bowl
- 8. 9" x 16.75" Utensil Holder
- 9. 15.75" x 16.75" 6-Bowl Serving Board

*Included accessories may vary by model.

Top-Mount Kitchen Workstation Sink

USE & CARE INSTRUCTIONS

CARE AND MAINTENANCE

- It is recommended to wash the basin frequently.
- Please clean only use warm soapy water and then dry with a soft cloth.
- Do not use wire brushes, detergents, abrasives and other supplies to clean, to prevent abrasion on the surface of the basin.
- Do not use hard or sharp objects to scratch the surface of the basin.
- · Pay attention to avoid collision.
- It is recommended to use wax to maintain the wash basin every six months.



RUB LIGHTLY
WITH SOFT CLOTH



CLEAN PERIODICALLY



CLEAN SINK WITH MILD ABRASIVE



HARSH CLEANERS



STEEL WOOL



LEAVING BLEACH ON FOR TOO LONG



ONE-YEAR LIMITED WARRANTY

Swiss Madison® products are made with quality materials and excellent craftsmanship to provide our customers with beautiful, durable, long-lasting products. Should there be any defects in materials or craftsmanship under regular use that are discovered within the first year after delivery, Swiss Madison® will provide replacement parts at no charge, or at its discretion, replace any product or part of the product that is deemed defective, under normal installation, use, service or maintenance. This warranty applies only to the original purchaser. Proof of purchase must be submitted with any warranty claim.

Swiss Madison® recommends that all installations of Swiss Madison® products to be conducted by a licensed plumber or contractor. Swiss Madison® will not be held responsible for any damage or product failure due to improper installation, misuse, or failure to utilize a licensed plumber or contractor for installation. Swiss Madison® is not responsible for any installation or removal costs.

THIS ONE-YEAR LIMITED WARRANTY WILL BE VOIDED IF:

- The installation instructions were not followed by the installer
- The product has been moved from its initial place of installation
- The product has in any way been modified from its original condition
- The product has been subjected to improper maintenance, abuse, misuse, excessive use of chemicals, accidents, or other damages

Swiss Madison® makes no warranty that its products comply with any local building or plumbing codes. It is the consumer's responsibility and obligation to determine local code compliance prior to and during installation.

Swiss Madison® is not responsible for any special, incidental or consequential damages associated with the installation, replacement, return or use of the original purchaser's product. This includes, but is not limited to: freight costs, labor, travel time, lost profit, home damages and other contingent liabilities and costs (including, without limitation, costs associated with 'professionals' or 'experts', investigations, audits, analyses, attorneys and any other professional/hired services). Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

The Swiss Madison® warranty is a comprehensive and explicit limit of liability. All other warranties are hereby disclaimed and waived.

QUESTIONS OR CONCERNS? Please contact us directly at: 1-434-MADISON (623-4766)



WARNING:

Contents of your order may contain sharp and possibly other harmful pieces and may cause hazard to children and adults. Swiss Madison® is not responsible in any way for personal injuries or damages.