


WWT
WESTINTRENDS
WWT

DESIGNED IN CALIFORNIA



POLY ADIRONDACK 50" PORCH SWING

THANK YOU!

We appreciate you for choosing WestinTrends!

Thank you for letting WestinTrends continue to offer accessible luxury trends, inspired by everyone!

JOIN THE WESTINTRENDS COMMUNITY

Sign up here:

[*https://westintrends.com/welcome*](https://westintrends.com/welcome)



QUESTIONS OR COMMENTS?

If you have questions reach out to
cs@westintrends.com

FOLLOW, SHARE, & LEARN



PRODUCT REGISTRATION

[*https://westintrends.com/apps/product-registration*](https://westintrends.com/apps/product-registration)



ACCESSIBILITY - COMMUNITY - VALUE - SUSTAINABILITY

! NOTICE

Do not overtighten screws. (Insert all screws before tightening screws.)

- Please do not exceed the weight limitations of this item.
- Do not stand on or use any part of this item as a step ladder.
- Firmly secure all bolts, screws, and nuts before use.
- Reconfirm that all bolts, screws, and nuts are secure every 90 days.
- Do not use or store this item in the proximity of open flame or flammable / combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.
- Please adjust the speed slowly when you use electric drill for assembling to avoid screw slipping.

NO TOOLS REQUIRED



SWING
600LBS
CAPACITY



2 PERSON
ASSEMBLY




UP TO 20 MIN.
ASSEMBLY

HARDWARE


1 BOLT M6 x 30mm  2 PCS	2 BOLT M6 x 60mm  4 PCS	3 SCREW M4 x 13mm  4 PCS	4 SCREW M6 x 55mm  2 PCS	5 SCREW M6 x 90mm  2 PCS
6 M6 NUT  4 PCS	7 M6 WASHER  4 PCS	8 EYE HOOK M8 x 35mm  2 PCS	9 EYE HOOK M8 x 60mm  2 PCS	10 CHAIN  2 PCS
11 M8 NUT  4 PCS	12 M8 WASHER  4 PCS	13 SCREW M6 x 80mm  2 PCS		

PARTS



PRODUCT ASSEMBLY - OVERALL VIEW

Look at following overall view of this swing and learn the exact position of each part to be assembled.





PRODUCT ASSEMBLY

1

Attach **Part G Left Cup Holder** to **Part C Left Arm** with 1 pc of **Hardware #1 Bolt**.

Do the same to attach **Part H Right Cup Holder** to **Part D Right Arm** with 1 pc of **Hardware #1 Bolt**.





PRODUCT ASSEMBLY

2

Attach **Part F Right Leg** to **Part D Right Arm** with cup holder with 1 set of **Hardware #2 Bolt, #7 Washer and #6 Nut** (see image below).

Attach the steel plate to the Arm with 2 pcs of **Hardware #3 Screw**.

Do the same to attach **Part E Left Leg** to **Part C Left Arm** with cup holder




PRODUCT ASSEMBLY

3

Attach the combined **Part C Left Arm** with cup holder and **Part E Left Leg** to **Part A Swing Seat** with 1 set of **Hardware #2 Bolt**, **#7 Washer** and **#6 Nut**.

Do the same to assemble **Part D Right Arm** with cup holder and **Part F Right Leg** to **Part A Swing Seat** with 1 set of **Hardware #2 Bolt**, **#7 Washer** and **#6 Nut**.

Attach 2 sets of **Hardware #9 Eye Hook**, **#12 Washer** and **#11 Nut** as below for the chains.




PRODUCT ASSEMBLY

4

Attach **Part B Backrest** to **Part A Swing Seat** with 2 pcs of **Hardware #13 Screw** and 2 pcs of **Hardware #4 Screw** (see image below).

Attach **Part B Backrest** to **Part C Left Arm** and **Part D Right Arm** with 2 pcs of **Hardware #5 Screw** (see image below).




PRODUCT ASSEMBLY

5

Attach 2 sets of **Hardware #8 Eye Hook**, **#12 Washer** and **#11 Nut** to **Part A Swing Seat** as below.

Thread the **Hardware #10 Chain** through the holes in the left armrest. Unscrew the thread lock to open the carabiner, hook it onto the front leg eyebolt, and tighten the lock to secure it. Attach the carabiner at the other end of the chain to the eyebolt on the swing seat using the same method.


Repeat these steps to install the second chain on the right side.



PRODUCT ASSEMBLY

6

Tighten all the screws, bolts, and nuts to ensure the swing is sturdy enough.



REGISTRATION & REFUND POLICY

<https://westintrends.com/apps/product-registration>



<https://westintrends.com/policies/refund-policy>



HAVING TROUBLE

- **Not sure how to assemble or missing pieces?**

Please contact our Customer Service Team for assistance at cs@westintrends.com

Have Order #, Part # or SKU ready to speed up customer service!

CLEANING TIPS

REGULAR CLEAN: Use a mixture of warm water and mild soap. Gently scrub the surface with a soft bristle brush to remove any dirt or stains.

QUICK CLEAN: You can simply wipe down the HDPE furniture with a damp cloth. The material's resilience makes it resistant to most spills and stains, ensuring a hassle-free maintenance routine.

Regular cleaning not only preserves the aesthetic appeal of your furniture but also helps extend its lifespan.

Pressure washer can be used for seriously deep-cleaning - **DO NOT exceed 1500 PSI** - this will remove any debris and dirt.