
INSTRUCTION MANUAL





Chenille Upholstered Dining Chair With Storage With Casters


() CARE & MAINTENANCE

Please keep this instruction for your future reference.

- Be careful when assembly, avoid hurting the top surface.
- Clean the chair with lukewarm water, mild detergent & soft cloth.
- Firmly secure all bolts before use, do not use any part of this item as a step ladder.
- Reconfirm that all bolts, screws, and nuts are secure every 90 days.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.
- Do not overtighten screws. (Insert all screws before tighten screws.)
- Please do not exceed the weight limitations of this item.








PRODUCT ASSEMBLY - OVERALL VIEW


Look at following overall view of this chair and learn the exact position of each parts to be assembled.



Place Part A Storage upside down onto flat surface.


Attach 4 pcs of Hardware #3 Casters to Part A Storage.

Tighten the casters by the wrench provided.






Place **Part B Backrest** and **Part A Storage** as below and attach them with 6 sets of **Hardware #1 Bolt**, **#2 Washer**.







Place Part C Seat Board onto Part A Storage as below.

Tilt the **Seat Board** up when storage is in use.







CLEANING TIPS

REGULAR CLEAN: Use a mixture of warm water and mild soap. Gently scrub the surface with a soft bristle brush to remove any dirt or stains.

QUICK CLEAN: You can simply wipe down the furniture with a damp cloth.

Regular cleaning not only preserves the aesthetic appeal of your furniture, but also helps extend its lifespan.