


BASEBALL HITTING NET

GETTING STARTED





Thank you for choosing the SKLZ Baseball Hitting Net. We are dedicated to providing you with the best tools and instruction possible to help you unleash your athletic potential. If there is anything else we can do to help you optimize your training, don't hesitate to send us an email **customerservice@sklz.com** or give us a call **1-877-225-7275**.

BEFORE YOU BEGIN:

- Read all the setup and usage instructions carefully before using. If the setup and/or usage instructions are not followed correctly, it could result in injury or damage to the product.
- Adult setup is recommended.
- Athletes under 18 years of age should use only under adult supervision.
- Make sure you have all of the Baseball Hitting Net components. Please contact SKLZ customer service toll free at 1-877-225-7275 if you are missing anything.

△WARNING:

- · Baseball Hitting Net is under tension when set up. Please take the utmost care when releasing the tension during disassembly. Failure to do so may result in injury.
- Do not climb or hang on the Baseball Hitting Net.
- When in use, make sure the Baseball Hitting Net is set up in a clear area to avoid injury and/or damage to property.
- To avoid pinching, use caution when connecting the push-button tubing.

CARE:

- When finished using, store the Baseball Hitting Net after use. Do not leave outdoors.
- Keep away from fire and heat sources.

1 YEAR LIMITED WARRANTY


This warranty does not cover damages resulting from accident, misuse, abuse or lost merchandise, and is only valid in the USA.

Questions? Email: customerservice@sklz.com or call toll free: 877-225-7275

Made in China. ©2017 Pro Performance Sports, LLC. All rights reserved. Manufactured and distributed by SKLZ/Pro Performance Sports: 2081 Faraday Avenue, Carlsbad, CA 92008 U.S.A. SKLZ is a registered trademarks of Pro Performance Sports, LLC., its subsidiaries and affiliates. Product features, appearance, and specifications may be subject to change without notice. Unauthorized duplication is a violation of applicable local and international laws.

IDEA SUBMISSION


If you have an idea for a new and innovative sports training product, visit SKLZ.com to submit your concept. Some restrictions may apply.



GETTING STARTED



1. Connect base center poles (A).



2. Attach the base legs (B) to the center (A).



3. Slide lower net poles **(D)** into the net sleeves **(E)**. Insert lower net poles **(D)** into the base legs. **(B)**



4. Insert upper net poles **(C)** into the lower net poles. **(D)**Slide the Net **(E)** up the poles and connect the clip at the top to the upper net poles.



5. Attach loops at the bottom corners of the net to the hooks on the base legs.



6. Attach hook and loop strap on the net bottom to the base center.



Place net in the desired location and ensure it is on level ground. Secure frame with included ground stakes (F).

NOTE: Care should be taken when pressing in the ground stakes. Base legs can be bent if driven too far into the ground or hard surface.

WARNING: Make sure the net is secured into the ground before play. During play, make sure the ground stakes are secured as loose ground stakes may cause injury.



