


INSTRUCTION MANUAL



Kids Outdoor 31" Square Poly Dining Table


V1.0

! CARE & MAINTENANCE

Please keep this instruction for your future reference.

- Be careful when assembly, avoid hurting the top surface.
- Clean the table with lukewarm water, mild detergent & soft cloth.
- Firmly secure all bolts before use, do not use any part of this item as a step ladder.
- Reconfirm that all bolts, screws, and nuts are secure every 90 days.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.
- Do not overtighten screws. (Insert all screws before tighten screws.)
- Please do not exceed the weight limitations of this item.

TOOLS REQUIRED



**TABLE
300 LBS
CAPACITY**



**1 PERSON
ASSEMBLY**



**UP TO 20 MIN.
ASSEMBLY**

HARDWARE

1


**M6 x 75mm
SCREW**



16 PCS

2

**ALLEN
WRENCH**




1 PC

PARTS

A


**TABLE TOP
WITH APRON**



1 PC

B


TABLE LEG



4 PCS

C

RAIL



4 PCS

D


**UMBRELLA
HOLE COVER**



1 PC

PRODUCT ASSEMBLY – OVERALL VIEW

Look at following overall view of this dining table and learn the exact position of each part to be assembled.




PRODUCT ASSEMBLY

1

Place **Part A Table Top** upside down on soft surface like carpet to avoid damage. Loosely attach 1 pc of **Part B Table Leg** to **Part A Table Top** with 2 pcs of **Hardware #1 Bolt**.


Pay attention to the different heights of base holes that meets the holes in the aprons.



PRODUCT ASSEMBLY


2

Attach **Part C Rail** to **Part B Table Leg** with 1 pc of **Hardware #1 Screw**.



3


Loosely attach 1 pc of **Part B Table Legs** to **Part A Table Top** and **Part C Rail** with 3 pcs of **Hardware #1 Screw**.



PRODUCT ASSEMBLY


4

Attach 2 pcs of **Part C Rails** to **Part B Table Legs** with 2 pcs of **Hardware #1 Screw**.



5


Do the same to assemble the rest **Part B Table Legs**, **Part C Rail** & **Part A Table Top**.



6

Tighten all the screws when all the parts are loosely attached.
Turn over the table and enjoy it now.

Remark: Please remove the umbrella hole cover when you insert the umbrella.



CLEANING TIPS

REGULAR CLEAN: Use a mixture of warm water and mild soap. Gently scrub the surface with a soft bristle brush to remove any dirt or stains.

QUICK CLEAN: You can simply wipe down the furniture with a damp cloth.

Regular cleaning not only preserves the aesthetic appeal of your furniture, but also helps extend its lifespan.