



ITEM: 6820-90201-80 Nine-Drawer Dresser  
6820-90201-85 Nine-Drawer Dresser  
6820-90201-99 Nine-Drawer Dresser

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.


HARDWARE PACK				
NO.	DRAWING	DESCRIPTION	SIZE	Q'TY
1		Anti - Tip Kit		1 PC

PARTS LIST				
NO.	DRAWING	DESCRIPTION	SIZE	Q'TY
1		Center Leg	91*38*38mm	1 PC

## STEP 1:

Install the Center Leg (1) in clockwise direction into the bottom of the case.

Remove it by the reverse way.




ITEM: 6820-90201-80 Nine-Drawer Dresser  
6820-90201-85 Nine-Drawer Dresser  
6820-90201-99 Nine-Drawer Dresser



Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.

## Tipping Restraint



Anti-tip kit is included for use.  
We recommend installing for  
safety reason.



Adjust leveler if needed to level  
dresser on uneven floor.