

IMPORTANT INFORMATION

⚠ CAUTION: Risk of scalding. High water temperature can cause severe burns. Set the water temperature at or below 120°F (49°C) following adjustment procedure in the valve Installation and Care Guide.

⚠ CAUTION: Risk of scalding. KOHLER low-flow showerheads/handshowers are designed for use with compatible KOHLER valves. When installing a low-flow product to an existing showering system, verify compatibility before showering. Do not use this KOHLER low-flow product with a shower valve that allows the water temperature to become too hot when other plumbing products are used.

Prior to using your shower, verify your new showerhead/handshower is compatible with your shower valve (located behind the wall):

- While standing outside the shower, turn on the shower valve. Do not step into the shower.
- Adjust the water to your typical showering temperature.
- Have someone flush the nearest toilet.
- With your hand, carefully check the water temperature from the showerhead/handshower while the toilet is refilling.
- If the water becomes significantly more hot, you will need to replace the shower valve with a compatible KOHLER valve or return your showerhead/handshower.

CAUTION: Risk of product damage. Do not hang accessories or other items on the product.

NOTE: Plumbing codes require approved backflow prevention devices be installed in-line to handshowers. Please consult local plumbing codes.

1. Run water to flush debris. Make sure the screen washer is seated in the hose. Thread the hose onto the handshower.
2. Rotate the lever to the minus (-) icon to pause or to the plus (+) icon to resume the spray.
3. **Maintenance:** To dislodge debris, rub the nozzles or sprayface while the water is running.
4. **Maintenance:** To improve the water flow, disconnect the handshower and clean the screen washer.

Need help? Contact the Customer Care Center at 1-800-456-4537.

For care and cleaning and other information, visit kohler.com/clean.

This product is covered under the KOHLER® Warranty: **Faucet Lifetime Limited Warranty**. For a hardcopy of warranty terms, contact the Customer Care Center. USA/Canada: 1-800-4KOHLER (1-800-456-4537), Mexico: 001-800-456-4537, kohler.com/warranty.


INFORMATIONS IMPORTANTES

⚠ ATTENTION : Risque de brûlures. Les pommes de douche/douchettes à faible débit de KOHLER sont conçues pour être utilisées avec des vannes KOHLER compatibles. Lors de l'installation d'un produit à faible débit sur un système de douche existant, vérifier la compatibilité avant de prendre une douche. Ne pas **utiliser** ce produit KOHLER à faible débit avec une vanne de douche qui permet à la température de l'eau de devenir trop chaude lorsque d'autres produits de plomberie sont utilisés.

Avant d'utiliser la douche, vérifier que la nouvelle pomme de douche/ douchette est compatible avec la vanne de douche (se trouvant derrière le mur) :

- Se tenir debout hors de la douche et ouvrir la vanne de douche. Ne pas entrer dans la douche.
- Ajuster l'eau à la température typique de douche.
- Demander à quelqu'un de tirer la chasse du W.C. le plus proche.
- Avec la main, vérifier avec précaution la température de l'eau, à partir de la pomme de douche/douchette alors que la toilette se remplit.

1



2

