

# FLEXSTEEL®



## W1020-8341 / 8342

### ROUND DINING TABLE

#### IMPORTANT


Carefully remove all parts from the carton, and put them individually on a soft cloth to prevent damage to the parts.

We have taken great care in the design of this product and request that you carefully and accurately follow our assembly instructions to ensure proper set-up.



#### Part List


#### Assembly Instructions 1/3




A. Table top  
1 piece



B. Pedestal  
1 piece




C. Pedestal base  
1 piece




D. Connecting Panel  
1 piece

#### Hardware List




Long Bolt  
Ø5/16"-18 UNC x 4-5/8"  
4 pieces




Short Bolt  
Ø5/16"-18 UNC x 1-1/4"  
8 pieces



Spring Washer  
Ø5/16" x 1.5mm  
12 pieces



Flat Washer  
Ø5/16" x Ø19mm x 1.5mm  
12 pieces



Hex Key  
5/32"  
1 piece

# FLEXSTEEL®


## Assembly Instructions 2/3

### IMPORTANT NOTES

- Do not tighten up all the bolts until each part is properly assembled.
- Keep the Hex Key in a safe place as you may need to tighten up the bolts in the future.
- Use a soft cloth between these parts and the floor.
- We recommend this product be assembled by at least two adults.


### STEP 1

Connect the Connecting Panel (D) and Pedestal (B) by inserting Short Bolts, Spring Washers, Flat Washers and fully tighten with Hex Key. (See Figure 1)



### STEP 2

Connect the Connecting Panel (D) and Table Top (A) by inserting Short Bolts, Spring Washers, Flat Washers and fully tighten with Hex Key. (See Figure 2)




# FLEXSTEEL®

## Assembly Instructions 3/3


### STEP 3

Connect the Pedestal base (C) and Pedestal (B) by inserting Long Bolts, Spring Washers, Flat Washers and fully tighten with Hex Key. (See Figure 3)



### STEP 4

Flip the table over, and adjust the levelers on the Pedestal base until the furniture is leveled. (See Figure 4)



### CARE INSTRUCTIONS

- To avoid scratches, do not place sharp or jagged objects directly on the table top.
- Do not place hot items directly on the table top.
- Use placemats or trivets under hot items and coasters under beverages to prevent marks and stains.
- Avoid the use of harsh chemicals or abrasive cleaning materials.
- Wipe the table clean with a soft, dry cloth after each use.
- Wipe up spills quickly with a soft, dry cloth.

Flexsteel Industries, Inc.

For Parts or Customer Service call

toll-free:

1-888-415-3979

Monday-Friday

8:00 a.m. -5:00 p.m.

(Central Time)

Email:

customersolutions@flexsteel.com

www.flexsteel.com