





ASSEMBLY INSTRUCTION





ITEM: SS719-PHZ3-012,089-Kramer Zero Gravity Power
Sofa with Power Headrest

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.


PART LIST

NO .	DESCRIPTION	SKETCH	QTY
A	Seat		1PC
B	Left Back Cushion		1PC
C	Right Back Cushion		1PC
D	Power cord		1PC



STEP 1 - Place Bracket into Sleeve and press top of back down firmly to lock your KD back in place.

STEP 2 - Connect the wire on back cushion and seat cushion



STEP 3 - Use the handcontroller to enjoy your Hooker Furnishings

CAUTION

Do not allow children to play on this mechanism or operate the mechanism. Leg rest folds down on closing so that child could possibly be injured. Always leave in an upright and closed position and keep hands feet clear of mechanism. Only the occupant should operate it.