# INSTRUCTION MANUAL




## (!) CARE & MAINTENANCE

### Please keep this instruction for your future reference.


- Be careful when assembly, avoid hurting the top surface.
- Clean the table with lukewarm water, mild detergent & soft cloth.
- Firmly secure all bolts before use, do not use any part of this item as a step ladder.
- Reconfirm that all bolts, screws, and nuts are secure every 90 days.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.
- Do not overtighten screws. (Insert all screws before tighten screws.)
- Please do not exceed the weight limitations of this item.







#### **PARTS**








## **PARTS**








# PRODUCT ASSEMBLY - OVERALL VIEW


Look at following overall view of this picnic table and learn the exact position of each part to be assembled.



#### **PRODUCT ASSEMBLY**




Place **Part A Table Top** upside down on soft surface like carpet to avoid damage. Loosely attach 2 pcs of **Part B Leg I** to the apron of the **Table Top** with 2 pcs of **Hardware #2 Screw**, 2 sets of **Hardware #3 Bolt** and **#4 Nut** as below.



2


Do the same to attach 2 pcs of Part C Leg II loosely to Part A Table Top with 2 pcs of Hardware #2 Screw, 2 sets of Hardware #3 Bolt and #4 Nut.



## **PRODUCT ASSEMBLY**


3

Attach the **Part D Rail** between 2 pcs of **Part B** and **Part C** with 4 pcs of **Hardware #1 Screw.** 



4


Attach 2 pcs of Part F Footrest Support to Part B and C Legs with 8 sets of Hardware #3 Bolt and #4 Nut.



# PRODUCT ASSEMBLY




Attach Part E Footrest to Part F Footrest Support with 8 pcs of Hardware #1 Screw.



6

Tighten all the screws, bolts and nuts to ensure the steady of this table.



## **CLEANING TIPS**

**REGULAR CLEAN:** Use a mixture of warm water and mild soap. Gently scrub the surface with a soft bristle brush to remove any dirt or stains.

QUICK CLEAN: You can simply wipe down the furniture with a damp cloth.

Regular cleaning not only preserves the aesthetic appeal of your furniture, but also helps extend its lifespan.