
KINCAID

SOLID WOOD SINCE 1946

ASSEMBLY INSTRUCTION

706-744 RANKIN RECTANGULAR LEG TABLE

www.kincaidfurniture.com
Phone : 828-728-3261.



IMPORTANT NOTES :


. Place all wooden parts on a clean and smooth surface such as a rug or carpet to prevent the parts from being scratched.

. Check to be sure that you have all parts and hardware.

. Remove all wrapping materials,including staples and packing straps before you start to assemble.

. Do not tighten all screws and bolts until completely assembled.

. Keep all hardware out of the reach of children.



NO.	PART DESCIPTION		Q'TY
A	Flat washer 5/16"*19		8pcs
B	Lock washer 5/16"		8pcs
C	Bolt 5/16"*50mm		8pcs
D	Allen key 4mm		1pcs