


Thank you for choosing Sunnydaze Decor. We stand behind our brand and the quality of the items we sell. Replacement parts or products will be sent at our discretion within the 1-year warranty period. Proof of purchase, with the date of purchase as well as photos of the merchandise defect, must be provided. Photos are used to determine the cause of defects and for future quality control. Register your warranty at <https://tiny.cc/SunnydazeWarranty>. If you have any questions, comments or concerns, feel free to contact us by phone at 833-982-1977, by email: [customerservice@sunnydazedecor.com](mailto:customerservice@sunnydazedecor.com), or via our contact us page at <https://tiny.cc/SunnydazeContact>








# DISPLAY STAND HMI-658

Assemble components on a soft, clean surface to avoid scratching or damaging the finish.



Inspect packaging to ensure all parts are accounted for before disposing of packing materials.



No.	PARTS	QTY.
A	 Base	1
B	 Pole	1
C	 Bolt ( <i>remove from part B</i> )	1
D	 Center Pole	1
E	 Tall Hooks	4 PC SET
F	 Medium Hooks	4 PC SET
G	 Short Hooks	2 PC SET

## ! HELPFUL HINT

Sunnydaze Decor advises reading this manual fully, and assembling the item soon after purchase. Check that all parts are accounted for and familiarize yourself with the assembly before beginning.

Save this manual for future reference.

# ASSEMBLY

## STEP 1

A: 1  
B: 1  
C: 1




Remove Bolt (C) from Pole (B).

Align Pole (B) with Base (A). Secure the components by tightening Bolt (C) through the underside of the base, into the pole.

## STEP 2

E: 2  
F: 2




Identify Tall Hook (E) with a nut built into the end; begin with this hook on the bottom.

Cross and stack the second Tall Hook (E) and two Medium Hooks (F).

## STEP 3


D: 1



Screw the shorter threaded end of Center Pole (D) into the Step 2 components.


## STEP 4

E: 2  
F: 2  
G: 2



Cross and stack Tall Hooks (E), Medium Hooks (F) and Short Hooks (G) onto the long threaded end of Center Pole (D).

## STEP 5



Connect the combined parts of Step 1 with the stacked decorative hooks by securing the long threaded end of Center Pole (D) into the top of Pole (B).

# Care & Maintenance

- 1. Safe Use:** Ensure weight is evenly distributed to prevent the stand from tipping over. Avoid hanging heavy objects from the hooks as it may cause the hooks to bend.  
Supervise children and pets while this item is in use. Do not allow children or pets to pull on, play with or climb on the stand as it may result in injury or property damage.
- 2. Care:** Cleaning often will keep the item looking like new.  
This item is not recommended for use outdoors. Exposure to moisture may cause connection points to rust.
- 3. Storage:** Store in a cool, dry indoor location. Storing in the original box will help prevent dust build-up.

## Cleaning

*Do not use harsh chemicals or abrasive materials to clean this item.*

- Dust with a soft, lint-free cloth such as a microfiber cloth or use a feather duster.
- If necessary, use a slightly damp cloth to wipe the item down. Dry with a soft, lint-free cloth.

### SAFETY STATEMENTS & WARNINGS

- Recommended for indoor use only.
- Do not bend hooks.
- Do not hang heavy objects from the hooks.
- Ensure weight is evenly distributed on the stand to prevent it from tipping over.
- This is not a toy. Always supervise children and pets.

**Any modification to the product or failure to follow recommended care will void the product warranty.**

### WARNING!

**Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.**