Your Dynarex Product is warrantied to be free of defects in materials and workmanship for the lifetime of the product for the original purchaser. This item was built to exacting standards and carefully inspected prior to shipment. This Limited Lifetime Warranty is an expression of our confidence in the materials and workmanship of our products and our assurance to the consumer of years of dependable service.

The Warranty shall not apply under the following conditions:

- · Problems arising from normal wear
- Problems arising from failure to adhere to the product instructions
- Problems arising from misuse, negligence, accident or improper operation, maintenance or storage
- Problems arising from modifications or unauthorized repairs, parts or attachments
- Products where the serial number has been removed or defaced
- Problems with non-durable components, such as rubber accessories, casters, and grips, which are subject to normal wear and need periodic replacement

Dynarex shall not be liable for any consequential or incidental damages whatsoever. Dynarex shall repair or replace defective products at its option. The foregoing warranty is exclusive and in lieu of other express warranties, if any, including the implied warranties of merchantability and fitness of a particular purpose. The remedy for any violation of the implied warranty shall be limited to repair or replacement of the defective product pursuant to the terms contained herein.

If you have a question about your Dynarex device or this warranty, please contact an authorized Dynarex dealer.









Pedal Exerciser

Folding • Hand/Feet





Manufactured for: Dynarex Corporation 10 Glenshaw Street • Orangeburg, NY 10962 USA • www.dynarex.com

ASSEMBLY INSTRUCTIONS

PARTS LIST:

- 1. Stabilizer
- 2. Stabilizer
- 3. Star Knob
- 4. Main Frame



STEP 1:

Connect the stabilizer with the main frame using the star knob and tighten firmly.



STEP 2:

Repeat step 1 for other side.



STEP 3:

Tighten the tension knob (3) on main frame (4).





RESISTANCE ADJUSTMENT



Turn the tension knob to adjust the paddle resistance. "High" means heavy resistance, "Low" means light resistance.

EXERCISE INSTRUCTIONS



HAND ROWING EXERCISE



PADDLE EXERCISE