



OutSmart™ Knob Covers (2pk)

HS2730500
White

- Prominent decoy button can be pushed by child, with no effect
- Flexible surface hides functional buttons in plain sight
- Easy installation - snaps together over doorknob
- Simple one-hand operation
- Front cover opens for access to door lock
- Fits most door knobs (up to 2 1/16 inches in diameter)



Package Type	Units Per	Height (inches)	Width (inches)	Depth (inches)	Weight (lbs)	Cubic Feet	UPC
Each	1	7.63	3.63	2.5	0.3	0.04	0884392600716
Inner Carton	6	11.4	7.9	4.0	1.8	0.21	10884392600713
Master Carton	24	17.0	12.2	9.0	7.2	1.08	20884392600710

