


INSTRUCTION MANUAL



Kids Outdoor Dining Chair

V1.0

! NOTICE

Please keep this instruction for your future reference.

- Be careful when assembling, avoid damaging the top surface.
- Clean the table with lukewarm water, mild detergent & soft cloth.
- Firmly secure all bolts before use, do not use any part of this item as a step ladder.
- Reconfirm that all bolts, screws, and nuts are secure every 90 days.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.
- Do not overtighten screws. (Insert all screws before tighten screws.)
- Please do not exceed the weight limitations of this item.

TOOLS REQUIRED



CHAIR
300 LBS
CAPACITY



1 PERSON
ASSEMBLY



UP TO 20 MIN.
ASSEMBLY

HARDWARE

1


SCREW
M6 x 55mm



8 PCS

2


SCREW
M6 x 85mm



8 PCS

3

SCREW
M6 x 45mm




4 PCS

PARTS

A

CHAIR SEAT



1 PC

B

REAR LEG



1 PC

C

FRONT LEG



2 PCS

D

RAIL



3 PCS

E


REAR LEG



1 PC

PRODUCT ASSEMBLY – OVERALL VIEW


Look at following overall view of this chair and learn the exact position of each parts to be assembled.



PRODUCT ASSEMBLY

1

Attach 3 pcs of **Part D Rail** to **Part B** and **Part E Legs** with 4 pcs of **Hardware #3 Screw** as below.




PRODUCT ASSEMBLY

2

Place **Part A Chair Seat** upside down on soft surface like carpet to avoid damage.


Attach 2 pcs of **Part C Front Leg** to the aprons of **Part A Chair Seat** with 4 pcs of **Hardware #1 Screw** and 4 pcs of **Hardware #2 Screw** as below.

Pay attention to match the holes in the aprons.



3

Attach the combined part (**Part B & Part E Rear Leg + Part D Rail**) to **Part A Chair Seat** with 4 pcs of **Hardware #1 Screw** and 4 pcs of **Hardware #2 Screw** as below.




PRODUCT ASSEMBLY

4

Check and tighten all the bolts again to ensure the chair is steady enough.

Enjoy this chair now.



CLEANING TIPS

REGULAR CLEAN: Use a mixture of warm water and mild soap. Gently scrub the surface with a soft bristle brush to remove any dirt or stains.

QUICK CLEAN: You can simply wipe down the furniture with a damp cloth.

Regular cleaning not only preserves the aesthetic appeal of your furniture, but also helps extend its lifespan.