


Spinning Double Rose Flower Stake


Assembly Instructions




Big Petal (2)



Small Petal (2)



Leaf Pole





Middle Pole





Stake Base



Step 1: Insert big petal (A) into leaf pole (C). Attach small petal (B) to big flower by turning it to the right on leaf pole (C) until it is firmly tightened.



Step 2: Repeat step 1 to attach the other big and small petals to leaf pole (C).



Step 3: Attach middle pole (D) to leaf pole (C) by turning it to the right until it is firmly tightened.



Step 4: Attach stake base (E) to middle pole (D) by turning it to the right until it is firmly tightened.

