



YOUTH POP-BACK TEE

GETTING STARTED



Thank you for choosing the SKLZ Youth Pop-Back Tee. We are dedicated to providing you with the best tools and instruction possible to help you prepare for your sport. If there is anything else we can do to help, don't hesitate to send us an email at customerservice@sklz.com or give us a call at **1-877-225-7275**.

BEFORE YOU BEGIN:

- Read all instructions carefully before using. If the instructions are not followed correctly, it could result in injury or damage to the product.
- Always check for wear and tear before use. If any is found, do not use the product.
- If you are missing any Youth Pop-Back Tee components, please contact SKLZ customer service toll free at **1-877-225-7275**.

WARNING:

PHYSICIANS WARNING: Not all exercise equipment and programs are suitable for everyone. It is recommended that you consult your physician before using this equipment or beginning this or any other exercise program.

- Athletes under 18 years of age should use only under adult supervision.
- When using your Youth Pop-Back Tee, please have others stay clear of the hitting area to reduce the risk of injury.
- Always wear a NOCSAE approved helmet. Face guard recommended.
- When using the Youth Pop-Back Tee with a net, position the tee far enough away from the net to allow the batter to swing freely, while still being close enough to ensure the net will capture a hit ball.

CAUTION:

- When in use, make sure your Youth Pop-Back Tee is in a clear area to avoid damage to property.

CARE:

- Do not leave the Youth Pop-Back Tee outdoors for extended periods of time.
- Keep away from fire and heat sources.
- Avoid storing the Youth Pop-Back Tee in extremely hot or cold environments as this could reduce the life span of the product.

PATENT #8,109,844

IDEA SUBMISSION


If you have an idea for a new and innovative sport training product, visit sklz.com to submit your concept. Some restrictions may apply.

1-YEAR LIMITED WARRANTY

This warranty does not cover damages resulting from accident, misuse, abuse or lost merchandise and is only valid in the USA. Need proof of purchase for warranty coverage. **Questions? Email customerservice@sklz.com or call toll free 1-877-225-7275.**

Made in China. ©2016 Pro Performance Sports, LLC. All rights reserved. Manufactured and distributed by SKLZ/Pro Performance Sports: 2081 Faraday Avenue, Carlsbad, CA 92008 USA. SKLZ is a registered trademark of Pro Performance Sports, LLC, its subsidiaries and affiliates. Product features, appearance and specifications may be subject to change without notice. Unauthorized duplication is a violation of applicable local and international laws.

IN THE BOX



ASSEMBLY




1. Insert bottom tube (B) into the base (A).



2. Line up center tube (C) with the push button facing down, to the holes on bottom tube (B).



3. Slip tee top (D) with the tee cup facing up, over center tube (C).



4. Adjust height by pushing the button into the desired hole of bottom tube (B).