

31.5" OUTDOOR SQUARE DINING TABLE WITH METAL FRAME

THANK YOU!

We appreciate you for choosing WestinTrends!

Thank you for letting WestinTrends continue to offer accessible luxury trends, inspired by everyone!

JOIN THE WESTINTRENDS COMMUNITY


Sign up here:

https://westintrends.com/welcome



OUESTIONS OR COMMENTS?

If you have questions reach out to cs@westintrends.com











PRODUCT REGISTRATION https://westintrends.com/apps/product-registration




ACCESSIBILITY - COMMUNIT V - VALUE - SUSTAINAB


() CARE & MAINTENANCE

Do not overtighten screws. (Insert all screws before tighten screws.)

- Please do not exceed the weight limitations of this item.
- Do not stand on or use any part of this item as a step ladder.
- Firmly secure all bolts, screws and nuts before use.
- Inspect and tighten all bolts on a regular basis to ensure proper performance and safety.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.
- We recommend the use of furniture covers to protect when not in use, and store in a dry and protective area during off season.



Look at following overall view of this table and learn the exact position of each parts to be assembled.




PAGe 1 OF 2

PRODUCT ASSEMBLY



Pick out Part B Table Legs and Part A Table Top from package.


Place **Part A Table Top** upside down on flat surface. Attach 4 pcs of **Part B Table Leg** to **Part A Table Top**, each leg with 3 sets of **Hardware #1 Bolt** and **#2 Washer**.





Check and tighten all the bolts again to ensure the table is steady enough.

Adjust the feet leveler to ensure four feet are evenly to the ground. Enjoy the table now.



REGISTRATION & REFUND POLICY

https://westintrends.com/apps/product-registration



https://westintrends.com/policies/refund-policy

HAVING TROUBLE

• Not sure how to assemble or missing pieces? Please contact our Customer Service Team for assistance at **cs@westintrends.com**

Have Order #, Part # or SKU ready to speed up customer service!

CLEANING TIPS

REGULAR CLEAN: Use a mixture of warm water and mild soap, rinse thoroughly and dry in the sun. Avoid harsh cleansers or polish and do not use bleach or acid on the metal product.

QUICK CLEAN: You can simply wipe down the furniture with a damp cloth.

Regular cleaning not only preserves the aesthetic appeal of your furniture but also helps extend its lifespan.

