# FLEXSTEEL°

### W1077-06


Millwork 76" Entertainment Console

### **IMPORTANT NOTE**

Carefully remove all the parts from the carton and put them individually on a soft cloth to prevent damage to the parts.

We have taken great care in the design of this product and request that you carefully and strictly follow our assembly instructions to ensure a completed product as it was designed.





Tool(s) recommended for assembly: Level and Screwdriver

# FLEXSTEEL®


## Assembly Instructions 2/3

#### **IMPORTANT NOTES**

- Do not tighten up all the bolts until each part is properly assembled.
- Keep the Hex Key in a safe place as you may need to tighten up the bolts in the future.
- Use a soft cloth between these parts and the floor.
- We recommend this product be assembled by at least two adults.


#### **STEP 1**

To assemble Console, attach Right Legs (R) and Left Legs (L) to Console, with 2 Long Bolt (C), 1 Short Bolt (D), 3 Spring Washer (B) and 3 Flat Washer (A) for each leg. Repeat this step on each leg. (See Figure 1.) IMPORTANT: Do not fully tighten all the bolts until all pieces are fitted together in the proper location. Tighten Center Support Leg (S) to Console by rotate the leg to the right. (See Figure 1.)



#### **STEP 2**

Adjust the levelers on the legs until the furniture is leveled. (See Figure 2.)



## FLEXSTEEL°


## Assembly Instructions 3/3

#### **IMPORTANT NOTES**


POSITION THE ANTI-TIPPING RESTRAINT AS CLOSE AS POSSIBLE TO THE TOP CENTER BACK OF THE CASE. REFER TO TIPPING KIT MANUFACTURER'S INSTRUCTIONS FOR ATTACHMENT

• Phillips screwdriver (not included) is required for assembling anti tipping kit.

•Assembly and installation of tip restraint by two adults is highly recommended.



Anti-tipping Hardware is pre-attached at back panel



### **CARE INSTRUCTIONS**

- To avoid scratches, do not place sharp or jagged objects directly on the table top.
- Do not place hot items directly on the table top.
- Use placemats or trivets under hot items and coasters under beverages to prevent marks and stains.
- Avoid the use of harsh chemicals or abrasive cleaning materials.
- Wipe the table clean with a soft, dry cloth after each use.
- Wipe up spills quickly with a soft, dry cloth.

Flexsteel Industries, Inc. For Parts or Customer Service call toll-free: 1-888-415-3979 Monday-Friday 8:00 a.m. -5:00 p.m. (Central Time) Email: customersolutions@flexsteel.com

www.flexsteel.com