# Care and using instructions

### **Battery Installation:**

- 1. Unscrew the upper cap with anti-clockwise direction and remove it from the body.
- 2. Fill 6x "AAA" batteries into the battery compartment as per the picture showing.
- 3. Put the upper cap back to the body and turn it to fix with clockwise direction.

#### Fill the pepper corns:

- 4. Unscrew the lower part of transparent chamber with clockwise direction and remove it from the body.
- Fill the pepper corns or sea salt into the chamber.
  Don't over fill. keep the pepper corns or sea salt
  80% full in the chamber as maximum limit.
- 6. Replace the chamber to the body and unscrew it to fix.

## Operating your pepper mill:

- 7. Turn it over your gravity pepper mill to start working
- 8. Adjust the top black adjuster to grind your pepper corns or sea salt with fine to coarse.

#### Notes:

The machine may stuck during using, please adjust the top black adjuster with anti-clockwise direction.

Or change your batteries ( Alkaline battery recommended)

Always keep clean and avoid contacting with water.

