



To override the Auto program:

- 1 Press the ▲ or ▼ button to activate the display.
- 2 Press the ▲ to raise or ▼ button to lower both the Heat and Cool set points.
- 3 Confirm the settings by pressing the middle button.

To change the individual Mode settings:

- 1 Press the ▲ or ▼ button to activate the display.
- 2 Press the — button to select Heat/Cool mode; press the + button to select the Fan mode.
- 3 Press the ▲ or ▼ button to select the mode.
- 4 When the desired mode appears, press the middle button to CONFIRM.
- 5 Press the ▲ button to raise or ▼ button to lower the set point for the currently selected mode.

