
Cuisinart Take Along Grill Stand

Open Dimensions: $54 \times 20 \times 30.5$ in $(137.2 \times 50.8 \times 77.5 \text{ cm})$

Aluminum Top: 24×15.6 in $(61 \times 39.6 \text{ cm})$ 48 lb (21.8 kg) weight limit

Side Tables: 20 lb (9.07 kg) weight limit **Storage Rack:** 35 lb (15.9 kg) weight limit

TO USE







With the carry handle away from you, lift the left side of the table top. Push up on the hinges to lock in place (hinge should be straight). Repeat on the right side.



4. The right table top should fit with the left table top at the middle. Make sure it is a secure fit.



5. Repeat step 3 with the side shelves. Making sure all 4 hinges are straight.

TO FOLD



 Lower side shelves by pushing the tab on each hinge outward, away from the table. Then push down on the shelves.



2. Lower table top by pushing the tab on each hinge down towards the middle of the frame. Then push down on the table tops.





4. Pull the two sides of the frame together.



5. Wrap lock strap around a leg from each side of the frame and button close.



For troubleshooting, FAQs or customer service, visit us at www.cuisinartgrilling.com/customerservice or contact us at 1-866-994-6390

Model #CFGS-222

Cuisinart® is a registered trademark under license to The Fulham Group. Distributed by The Fulham Group, Newton, MA. 02466 U.S.A.