

# Cuisinart®

## Hard Anodized Nonstick Cookware

---

### **BEFORE USING FOR THE FIRST TIME**

Remove all labels. Wash cookware and lids in warm water with a mild dish soap. Rinse thoroughly in warm water and wipe dry with a soft dishtowel.

### **HEALTHIER COOKING, EASY CLEANING**

When cooking with your Cuisinart® Hard Anodized Nonstick Cookware, you do not need to add oil or butter to prevent foods from sticking. If you wish to enhance the flavor and appearance of foods, you need only add a minimum amount to the nonstick surface of your cookware.

### **STOVETOP COOKING**

Select a burner size that matches the diameter of the pan bottom. When cooking over a gas burner, make certain that the flame touches only the bottom of the pan. If the flame extends up the sides of the pan, energy is wasted.

### **ESSENTIAL PRECAUTIONS**

Never use Cuisinart® Hard Anodized Nonstick Cookware on high heat or food will burn. The aluminum core of this cookware heats quickly, and its even heat distribution prevents hot spots. The dark interior color also allows food to cook more quickly with less heat. We recommend using a low to medium setting for most cooking. To boil water, medium-high is sufficient. Never leave Cuisinart® Cookware or any pan empty over a hot burner. Doing so can ruin the pan and cause damage to the stovetop.

### **OVEN COOKING TEMPERATURE**

Cuisinart® Hard Anodized Nonstick Cookware can be used in the oven up to 500°F. Glass lids are oven safe up to 450°F. Using Cuisinart® Cookware in the oven will cause the handles as well as the pan to become hot. Use pot holders or oven mitts when removing the cookware from the oven.

### **PROPER COOKING UTENSILS**

We recommend using plastic or wooden utensils in your Cuisinart® Cookware to maintain its appearance and performance. Refrain from cutting foods or using sharp utensils such as forks, knives, mashers, or whisks, which can scratch the cooking surface.

### **EASY MAINTENANCE**

Let your Cuisinart® Hard Anodized Nonstick Cookware cool before cleaning. The reinforced nonstick system and the smooth exterior ensure easy cleaning. Cookware should be washed by hand with hot sudsy water and a sponge or soft dishcloth. Do not use steel wool or other metal or abrasive pads that can scratch your cookware. After washing, rinse thoroughly and dry immediately to maintain your Cuisinart® Cookware's flawless finish. Do not put in the dishwasher since harsh detergents will harm the exterior finish.

### **CLEANING THE EXTERIOR**

Cuisinart® Hard Anodized Nonstick Cookware has a smooth exterior finish, making it easier to clean and maintain. Food residue or buildup on the exterior of your cookware can easily be removed with any nonabrasive cleaning product. The exterior of Cuisinart® Cookware, like other brands, will show wear with continuous use. This condition will not in any way affect the superior cooking performance of your cookware.

### **CONVENIENT STORAGE**

Hanging pans by their handles on a cookware rack provides convenient, safe storage for your Cuisinart Cookware. Use care if you store your cookware in cabinets or drawers. Careless stacking and crowding may cause scratches.

## LIFETIME WARRANTY

Subject to the exclusions and limitations contained herein, Conair LLC dba Cuisinart (“Cuisinart”) warrants that this Cuisinart® Hard Anodized Cookware will be free from material defects in materials and workmanship under normal home use conditions throughout the original purchaser’s lifetime, beginning on the date this Hard Anodized Cookware was purchased in its original, sealed packaging, unless otherwise specified in this Lifetime Warranty. This Lifetime Warranty is only for U.S. consumers (defined herein as purchasers at retail for personal, family, or household use) who originally purchase the Hard Anodized Cookware from Cuisinart or an authorized Cuisinart® reseller (if you are unsure whether a retailer or other point of sale is an authorized or unauthorized Cuisinart reseller, contact Cuisinart).

This Lifetime Warranty does NOT cover:

- Normal wear and tear;
- Any Hard Anodized Cookware purchased by commercial purchasers or for commercial or non-household uses;
- Accessories, parts, or software added to the Hard Anodized Cookware after the system is shipped from Cuisinart;
- Any costs associated with the replacement or repair of the Hard Anodized Cookware, including labor, installation, or other costs incurred by you without prior Cuisinart approval;
- Damage to the Hard Anodized Cookware, defective conditions, or nonconformities due to: (1) external causes, including shipping, accidents, abnormal conditions (such as a mechanical or environmental); (2) usage not in accordance with Hard Anodized Cookware instructions; (3) misuse, neglect, unauthorized alteration, unauthorized repair; and (4) acts of god or other events beyond Cuisinart’s control;
- Though necessary repairs and maintenance might be performed by any company, damage caused by you or any nonauthorized third party may void, this Lifetime Warranty;
- Damage caused by accessories or replacement parts not specifically authorized by Cuisinart, may void this Lifetime Warranty; and
- Any Hard Anodized Cookware where the original Hard Anodized Cookware identification markings (trademark or serial number) have been removed, altered, or obliterated from the Hard Anodized Cookware.

It is recommended that you visit the website, <https://cuisinart.registria.com>, for a fast, efficient way to complete your Hard Anodized Cookware registration. However, Hard Anodized Cookware registration does not eliminate the need for the consumer to maintain the original proof of purchase in order to obtain the warranty benefits. In the event that you do not have proof of purchase date, the purchase date for purposes of this Lifetime Warranty will be the date of manufacture.

## HASSLE-FREE REPLACEMENT WARRANTY

If the Hard Anodized Cookware that is the subject of this Lifetime Warranty fails during the warranty period for reasons covered by this Lifetime Warranty, Cuisinart will, at its option, repair the Hard Anodized Cookware, replace the Hard Anodized Cookware with another identical or reasonably equivalent Hard Anodized Cookware, or if Cuisinart is unable to repair or replace the Hard Anodized Cookware, refund the purchase price, less the amount directly attributable to the consumer’s prior usage of the Hard Anodized Cookware. To obtain a return shipping label, visit us at <https://www.cuisinart.com/customer-care/product-assistance/product-inquiry/>, or call our Consumer Service Center toll-free at **1-800-726-0190** to speak with a representative.

Upon receipt of the Hard Anodized Cookware, Cuisinart will inspect the Hard Anodized Cookware and, if required under this Lifetime Warranty, attempt to repair, replace, or refund the Hard Anodized

Cookware within thirty (30) days. However, there may be delays beyond Cuisinart's control, in which case that time period may be extended as reasonably necessary.

**IMPORTANT:** If the nonconforming Hard Anodized Cookware is to be serviced by someone other than Cuisinart's Authorized Service Center, please remind the servicer to call our Consumer Service Center at **1-800-726-0190** to ensure that the problem is properly diagnosed, the Hard Anodized Cookware is serviced with the correct parts, and the Hard Anodized Cookware is still under warranty.

### **CALIFORNIA RESIDENTS ONLY**

The Lifetime Warranty period begins on the date the Hard Anodized Cookware was delivered, which may be different than the date the Hard Anodized Cookware was purchased. California residents also have the option of obtaining the benefits of this Lifetime Warranty by bringing the Hard Anodized Cookware to (A) the store where it was purchased or (B) another retail store that sells Cuisinart Hard Anodized Cookware of the same type. The retail store shall then, according to its preference, either repair the Hard Anodized Cookware, refer the consumer to an independent repair facility, replace the Hard Anodized Cookware with another identical or reasonably equivalent Hard Anodized Cookware, or refund the purchase price less the amount directly attributable to the consumer's prior usage of the Hard Anodized Cookware. California residents may also, according to their preference, return nonconforming Hard Anodized Cookware directly to Cuisinart for repair or, if necessary, replacement with another identical or reasonably equivalent Hard Anodized Cookware by calling our Consumer Service Center toll-free at **1-800-726-0190**. Cuisinart will be responsible for the cost of such repair, replacement, and/or shipping and handling for such nonconforming Hard Anodized Cookware under warranty.

THIS LIFETIME WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS THAT VARY FROM STATE TO STATE OR BY JURISDICTION. IN THE EVENT THIS LIFETIME WARRANTY IS BREACHED, YOU MAY HAVE CLAIMS FOR REPLACEMENT, DAMAGES, OR OTHER PENALTIES

### **LIMITATIONS OF LIABILITY/ADDITIONAL LIMITATIONS AND EXCLUSIONS**

ALL EXPRESS AND IMPLIED WARRANTIES ARE LIMITED IN DURATION TO THE LIFETIME WARRANTY PERIOD. NO WARRANTIES APPLY AFTER THAT PERIOD. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THIS LIMITATION MAY NOT APPLY TO YOU. CUISINART'S RESPONSIBILITY UNDER THIS OR ANY OTHER WARRANTY, IMPLIED OR EXPRESS, IS LIMITED TO REPAIR, REPLACEMENT, OR REFUND, AS SET FORTH ABOVE. THESE REMEDIES ARE THE SOLE AND EXCLUSIVE REMEDIES FOR ANY BREACH OF WARRANTY. TO THE MAXIMUM EXTENT PERMITTED BY LAW, CUISINART IS NOT RESPONSIBLE FOR ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES RESULTING FROM ANY BREACH OF WARRANTY OR UNDER ANY OTHER LEGAL THEORY (INCLUDING, BUT NOT LIMITED TO, LOST PROFITS, DOWNTIME, GOODWILL, DAMAGE TO OR REPLACEMENT OF EQUIPMENT AND PROPERTY, AND ANY COSTS OF RECOVERING, REPROGRAMMING, OR REPRODUCING ANY PROGRAM OR DATA STORED IN OR USED WITH A SYSTEM CONTAINING THE HARD ANODIZED COOKWARE), EVEN IF CUISINART HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU. ALL EXPRESS AND IMPLIED WARRANTIES ARE LIMITED IN DURATION TO THE LIFETIME WARRANTY PERIOD. NO WARRANTIES APPLY AFTER THAT PERIOD. SOME STATES (OR JURISDICTIONS) DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THIS LIMITATION MAY NOT APPLY TO YOU.

This Lifetime Warranty is issued by:

Conair LLC

1 Cummings Point Road

Stamford, CT 06902

1-800-726-0190