

Cuisinart™




Grilluminate Extending Grill Light CGL-330 INSTRUCTIONS

Set Up

1. Slide battery door off
2. Insert 3AAA Batteries as indicated
3. Reattach battery door
4. Put Grill Clamp on grill handle with clamp screw oriented vertically and adjust the clamp screw to secure the light

Parts of the Grill Light



Use and Care

1. Turn the light on with the on/off button
2. Adjust angles and lights to best suit your grilling
3. Wipe clean with moist towel
4. Store in dry place

IMPORTANT: Do not leave out overnight especially in inclement weather. This light is not waterproof.

For customer service call 1-866-994-6390