Cuisinart





CGL-502

MAGNETIC LED GRILL LIGHTS 2-PACK INSTRUCTIONS

SET UP

- 1. Unscrew the bottom piece
- 2. Insert 3 AAA batteries (not included)
- 3. Screw the bottom piece back onto the body

USE AND CARE

- 1. Turn the light on and off by pressing the button located on the body of the light
- 2. Place light on metal surface of grill
- 3. Adjust neck to best suit your grilling
- 4. Wipe clean with moist towel
- 5. Store in a dry place

IMPORTANT: Do not leave out overnight especially in inclement weather. This light is not waterproof.