


2 Drawer Nightstand

196861042676
196861044618
196861051203



ASSEMBLY INSTRUCTIONS

Before You Begin: (Phillips screw driver required, not included)

Please identify all component parts and hardware pieces required before you begin. Carefully remove all of the components from the packaging and set a side for assembly. Assemble on a soft surface to prevent scratching during assembly.

Caution:

Tighten all components securely before use. Failure to do so may result in personal injury.

DO NOT use any sharp objects to open plastic wrapped components as damage to product or components may result.

Warning :


CHOKING HAZARD - Small Parts. Adult Assembly Required.

DO NOT ALLOW CHILDREN TO CLIMB ON FURNITURE


Serious or fatal injuries can occur from furniture tipping over. You must install Tipping Restraint Hardware (whereincluded) to help prevent the unit from tipping and causing accidental injury, instability, death or damage. The tipping restraint is intended only as a safety measure, it is not a substitute for proper adult supervision.

To help prevent furniture from tipping over it must be permanently attached to the wall. Anti-Tip Safety Wall Straps suitable for the unit weight and wall materials (if not included) should be purchased and installed.


Parts List



A Top Panel x 1




B Support Bar x 4




C Plug Support Bar x 1



D Back Panel
x 2



E Side Panel
(Left) x 1




F Side Panel
(Right) x 1




G Shelf Panel x 1




H Shelf-Drawer
Head x 1




J Drawer Head
x 2



K Drawer Back
x 2



L Drawer Side
(Left) x 2



M Drawer Side
(Right) x 2



N Drawrt Bottom
x 2

Hardware List



1 M6 x
15mm JCB
x 8



2 M6 x
40mm JCB
x 10




3 M4 x 25mm
Wood Screw
x 16



4 M4 x 20mm
Wood Screw
x 8



5 M4 x 16mm
Wood Screw
x 18



6 M10 x 40mm
Wood Dowel
x 2




7 Knob x 3



8 M4 x 20mm
Wood Screw
x 3



9 'L' Bracket
(5005-3)
x 4




10 Mini Fix Euro Bolt
34mm x 2



11 Mini Fix Housing
x 2




12 Allen Key
x 1




13 Plug(Big)
x 1


STEP 1 :




STEP 2 :



STEP 3 :




STEP 4 :





STEP 5 :


Step 1
Use the ball end of Allen key to start the bolt.



Step 2
Tighten fully with the straight end.




STEP 6 :




Step 1

Use the ball end of Allen key to start the bolt.




Step 2


Tighten fully with the straight end.




STEP 7 :




STEP 8 :




STEP 9 :




STEP 10 :




STEP 11 :





STEP 12 :




STEP 13 :



STEP 14 :



STEP 15 :



Lift the LEFT side clip up.

Push the Right side clip down.

Quality and Safety Guidelines:

- Please follow the static and dynamic weight capacity limits provided on this item. If you are unsure of the weight capacities for this product, email us at customerexperience@theubiquegroup.com or call 866-552-2810.
- Please use this item on a stable, level surface only. All legs, feet should contact the flooring surface when in use. Do not use this item if any instability is detected.
- Never push, pull or drag this product.
- Adult supervision required.
- For maintenance instructions and replacement parts, please email us at customerexperience@theubiquegroup.com or call 866-552-2810.
- This item is intended to be used as a table only. Do not climb, stand or sit on this item. Do not use this item as a TV stand. Do not place heavy objects on top of this product.
- The item is intended to be used indoors.
- Please inspect this product regularly to make sure there are no damaged or worn parts. Also inspect to make sure all hardware is tightened correctly and securely. For inspection instructions, please email us at customerexperience@theubiquegroup.com or call 866-552-2810.
- If any parts are damaged or worn, please stop using the product. Repair this product with manufacturer supplied parts only.
- For product longevity, product safety and product integrity, protect from wet and humid weather or other wet, humid or moist conditions and store indoors in a dry location. For additional storage and usage instructions, please email us at customerexperience@theubiquegroup.com or call 866-552-2810.
- Please visit www.theubiquegroup.com for our product warranty details or email us at customerexperience@theubiquegroup.com or call 866-552-2810.