



WHAT'S IN THE BOX



* Charge the speaker before first use. For safety and peak performance, use genuine JBL batteries. Non-original batteries may pose safety and reliability risks.

** The plug type and the quantity of power cords, microphones, and microphone holders vary by regions.

BLUETOOTH PAIRING



PLAY



LIGHTSHOW



Apply lightshow presets and more with the JBL app.

APP



Download and install the JBL app to get more from the product.




MICROPHONE



MULTI-SPEAKER CONNECTION




CHARGING



Due to local laws and regulations, the Powerbank function may be unavailable in certain regions. Please refer to local regulations. | 由于当地法律法规的限制，移动电源功能在某些地区可能无法使用。请参考当地相关规定。

MICROPHONE HOLDER




BATTERY REPLACEMENT

① Remove the Old Battery




② Insert the New Battery



Charge the battery before first use.

SPLASH PROOF IPX4



Do not change your speaker until it is completely dry and clean.

