kids2™

File Name: 11896_7L_PL020926.ai
Brand: **Bright Starts - Disney**
Category: Bouncer
Product Name: MICKEY MOUSE Happy Triangles Vibrating Bouncer
Package Designer: Nureen/Nico
Product Manager: LEAVE BLANK
Engineer: LEAVE BLANK
Languages: Languages on Package 3/7
Dimensions: XX"W x XX"H x XX"D

100% 75% 50% 25% 10% 3% 2% 1% Color

Packaging Prints
PMS 3248 C plus CMYK
L*75.63 a*-32.76 b*-2.9

PMS 3248 C
Cyan
Magenta
Yellow
Black

press5IGN CMYK 1 Spot_Colourbar_ISO 12647-2 Coated White Backing v6_labels_below i1Pro Contrast Bars.eps

press5IGN CMYK 1 Spot_Colourbar_ISO 12647-2 Coated White Backing v6_labels_below.eps

There are two color bars on this proof and in the art file. One to be used with X-rite 11 Pro Spectrophotometer. The other can be used with most other spectrophotometers.
Printers must repeat one of the two color bars all the way across the width (gripper edge) of the press sheets on sample runs and production runs. Failure to comply will result in the remaking of film and/or plates at your cost.
数码捕以及设计文件包含了两种色带。一种适用于X-rite（爱色丽）11 Pro 分光光度计，另一种适用于其它大部分的分光光度计。在打样或者批量生产时，印刷厂必须选择其中一种色带并重复添加直到覆盖整张纸的宽度（四口边）。
没有按照上述要求而导致重新出菲林、出版的费用将由印刷厂承担。

Short
UPC EXAMPLE
1.125"
0.25"
FOR REFERENCE ONLY
0 74451 11803 4

MICKEY MOUSE Happy Triangles™

Vibrating Bouncer • *Saltador con Vibración* • **Transat Vibrant**
Vibrierende Wippe • **Wibrujący Bujaczek** • *Sdraietta Vibrante*
Trillend Wipstoeltje

1. COMFORT. Soothing vibrations + deep seat provides comfort and support
   CONFORT. Vibrations apaisantes + siège profond, confort et maintien assurés
2. SAFETY • Adjustable 3-point harness
   SÉCURITÉ • Harnais à 3 points réglable
3. CONVENIENCE • Removable toy bar makes it a breeze to get baby in and out • Seat pad is easy to clean • 2 playtime toys to entertain
   FONCTIONNALITÉ • C'est un jeu d'enfant d'installer et de retirer bébé grâce à la barre d'activités amovible • Le coussin du siège est facile à nettoyer • 2 jouets amusants
4. THE MAGIC OF MICKEY • Your little Mickey Mouse fan will be all smiles
   LA MAGIE DE MICKEY • Votre petite fan de Mickey Mouse sera tout sourire !

brightstarts.com

KIDS2, LLC ATLANTA, GA USA 30305 • 1-800-230-8190

ES
1. CONFORT. Vibraciones relajantes + asiento de gran profundidad que proporciona comodidad y apoyo
2. PROTECCIÓN • Arnés ajustable de 3 puntos
3. CONVENIENCIA • La barra de juguetes desmontable hace que colocar y sacar al bebé sea muy fácil y rápido • La almohadilla del asiento es fácil de limpiar • 2 juguetes para entretenimiento
4. LA MAGIA DE MICKEY • ¡Tu pequeña aficionada a Mickey Mouse no dejará de sonreír!

DE
1. KOMFORT. Beruhigende Vibrationen + tiefer Sitz für Komfort und Unterstützung
2. SICHERHEIT • Verstellbarer Dreipunktgurt
3. BEQUEMLICHKEIT • Die abnehmbare Spielzeugstange macht es zu einem Kinderspiel, das Baby rein und raus zu heben • Sitzpolsterist leicht zu reinigen • 2 Spielzeugen zur Unterhaltung
4. Der Zauber von Micky • Ihr kleiner Micky-Maus-Fan wird • über das ganze Gesicht strahlen!

PL
1. WYGODA. Kojące wibracje + głębokie siedzisko zapewniają wygodę i podparcie
2. BEZPIECZEŃSTWO • Regulowane 3-punktowe szelki bezpieczeństwa
3. FUNKCJONALNOŚĆ • Zdejmowany pałąk z zabawkami ułatwia wkładanie i wyjmowanie dziecka • Podkładka siedziska jest łatwa w czyszczeniu • 2 zabawki zapewniające rozrywkę
4. MAGIA MYSZKI MICKEY • Twój mały fan Myszki Miki nie przestanie się uśmiechać

IT
1. COMFORT. Vibrazioni rilassanti + seduta avvolgente per comfort e sostegno
2. SICUREZZA • Aggancio regolabile a 3 punti
3. PRATICITÀ • La barra giocattoli rimovibile rende porre il bambino dentro e fuori un gioco da ragazzi • Imbottitura del seggiolino facilmente lavabile • 2 giochi ricreativi per l'intrattenimento del bambino
4. LA MAGIA DI TOPOLINO • Il tuo piccolo fan di Topolino sarà tutto sorrisi!

NL
1. COMFORT. Kalmerende trillingen + diepe zitting voor comfort en ondersteuning
2. VEILIGHEID - Verstelbaar 3-puntstuigje
3. GEMAK - Afneembare speelgoedstang om baby er gemakkelijk in zetten en uit te halen - Zitkussen is gemakkelijk te reinigen - 2 speeltjes voor speelplezier
4. DE MAGIE VAN MICKEY - Je kleine Mickey Mouse-fan zal in de wolken zijn

REG. NO. PA-13259(CN)
ALL NEW MATERIALS
TOY BAR
POLYETHYLENE FOAM
NO DE PERMIS PA-13259(CN)
TOUS LES NOUVEAUX MATÉRIAUX
BARRE À JOUET
MOUSSE DE POLYÉTHYLÈNE

ASTM F2167 ASTM F963 CE UKCA

FR DONNEZ OU RECYCLEZ — ASSOCIATION OU MAGASIN OU DÉCHÈTERIE
Adresses sur quefairedemesdechets.fr

FR Donnez ou recyclez vos meubles. — Association Magasin Déchèterie
https://quefairedemesdechets.fr

FR ÉLÉMENTS D'EMBALLAGE

FR Cet appareil se recycle — À DÉPOSER EN MAGASIN OU À DÉPOSER EN DÉCHÈTERIE
Points de collecte sur www.quefairedemesdechets.fr
Privilégiez la réparation ou le don de votre appareil !

©Disney
www.disney.com

UPC here 80%

Disney MICKEY MOUSE

EN 1. Adult assembly required. WARNING: Stop using the product when the child starts trying to sit up. WARNING: Never let the child sleep in this product. IMPORTANT: Remove all packaging and fasteners before giving product to child. Retain this information for future reference. Contents may vary slightly from those pictured. Actual product color may vary slightly from those shown. Some assembly required. Adult supervision required during assembly. Tools needed: Phillips screwdriver (not included) 2. Use only batteries specified. Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries. Do not use rechargeable batteries unless removed from the product. Do not recharge batteries unless they are of the rechargeable type. Do not attempt to recharge batteries not intended to be recharged. Remove exhausted batteries from the product. Remove batteries if product will not be used for an extended period of time. Do not short-circuit the supply terminals. Batteries should be inserted with correct polarity. Dispose of batteries safely. Do not dispose of batteries in fire. Batteries may explode or leak. Clean battery contacts of the product and batteries before assembling. Do not mix batteries of different brands. Do not mix batteries of different types. Do not use batteries with damaged casing. Do not use batteries with exposed or damaged contacts. Do not use batteries that are leaking. Do not use batteries that are deformed. Do not use batteries that are corroded. Do not use batteries that are damaged. Do not use batteries that are dirty. Do not use batteries that are wet. Do not use batteries that are cracked. Do not use batteries that are broken. Do not use batteries that are bent. Do not use batteries that are scratched. Do not use batteries that are chipped. Do not use batteries that are peeled. Do not use batteries that are faded. Do not use batteries that are discolored. Do not use batteries that are warped. Do not use batteries that are swollen