



Congratulations on the purchase of your new DMI Sports Table hockey table. Our products are designed and manufactured to give you years of game playing enjoyment.

☒ *KEEP BOX AND PACKING MATERIAL UNTIL TABLE HAS BEEN COMPLETELY ASSEMBLED.*

☒ *ALL DAMAGE MUST BE REPORTED TO DMI WITHIN TEN DAYS OF RECEIPT.*

☒ *If you have any problems with your new product,*

PLEASE DO NOT RETURN IT TO THE STORE.

Please contact us:

1.800.399.4402

FAX: 215.283.9573

Please have your model number when inquiring about parts.

Or write to:

DMI Sports

Customer Service

1300 Virginia Drive

Suite 401 Ft Washington,

PA 19034

Please visit our web site at:

www.dmisports.com

When contacting DMI Sports, please provide your model number and item number (if applicable) if requesting a replacement part.

Item numbers can be found inside this owners manual.

Your Model Number **HT12 Series**


Your model number is also located on the original carton. These instructions are also available online at: www.dmisports.com.

IMPORTANT!

Please Keep Your Instructions! (You will need your Model number should you need to contact us.) Before attempting assembly, please read through this instruction book to familiarize yourself with all the parts and assembly steps. We recommend that two adults assemble this table. Please refer to the Parts Identifier on the following page and be sure that all parts have been included. Although extremely rare, occasionally a part may be missing. If you are missing a part, or if you have any questions, please call our customer service department at 1.800.423.3320 Mon-Fri between the hours of 9:00am and 5:00pm E.S.T; or you can reach us at: www.dmisports.com.

Do not return the game to the store. Please contact us first at: 1.800.423.3320 or on our website at: www.dmisports.com.

TWO ADULTS ARE REQUIRED TO ASSEMBLE THIS HOCKEY TABLE







TOOLS REQUIRED FOR ASSEMBLY:


- Phillips Head Screw driver- Not Included
- Level recommended- Not Included
- Wrench - Included

PARTS IDENTIFIER




HARDWARE PARTS

H1	Qty. 12	H2	Qty. 12	H3	Qty. 8	H4	Qty. 4
							
Leg Bolt RPHT12-H1		Washer, Leg RPHT12-H2		1/2" Screw RPHT12-H3		Thumb Screw RPHT12-H4	

ACCESSORY PARTS

A1	Qty. 2	A2	Qty. 2	A3	Qty. 2	H5	Qty. 1
							
Pusher RPHT12-A1		Pusher Felt RPHT12-A2		Small Puck RPHT12-A3		Wrench RPHT12-H5	

ASSEMBLY PARTS

P1	Qty. 1	P2	Qty. 2	P3	Qty. 2	P4	Qty. 2
							
Main Frame RPHT12-P1		Left Leg RPHT12-P2		Right Leg RPHT12-P3		Crossbar RPHT12 - P4	
P5	Qty. 2	P6	Qty. 2	P7	Qty.1		
							
Goal RPHT12 - P5		Blind Post RPHT12-P6		Extreme™ Blind RPHT12-P7			


ASSEMBLY

NOTE: Please leave Main Frame (P1) face down in the carton that it ships in until the legs are attached. All images are shown UP-SIDE-DOWN until the table is turn up on its legs. Unpack all contents and lay out on the floor. Verify all parts listed on parts list are present.

STEP 1.


Attach the Left Leg (P2) and Right Leg (P3) to the Main Frame (P1) as shown in FIG 1. Secure one leg using Leg Bolt (H1) and Washer (H2) before placing the Crossbar (P4) between the left and right legs. Once the Crossbar is in place, secure the second leg. Repeat this step for the second pair of legs on the other end of the table before turning the table over onto its legs. Two adults should turn the table over. Be careful not to rest the table on its side as this may damage the legs.

Note: Do not turn table over during assembly without assistance. Applying sideways pressure on the legs will result in breakage, which is not covered by the warranty.



STEP 2.

When the table is turned over onto its legs, attach the Goal (P5) on both ends of the table using Screw (H3) as shown in FIG 2.



ASSEMBLY

STEP 3.

Attach Blind Posts (P6) on each side of the table using Thumb Screw (H4). Be sure to attach the blind posts with the tracks facing the table. inserting the blind (P7) in between the two posts. Set it to your desired height. The Extreme™ blind is removable if traditional play is desired.




FIG 3

PARTS RE-ORDER FORM

Send this form along with your
check or money order payable to:

HT12 Series Hockey Table

DMI SPORTS

1300 Virginia Drive., Suite 401
Ft Washington, PA 19034

www.dmisports.com

DATE: _____

NAME: _____

ADDRESS: _____ PHONE _____

CITY: _____ STATE: _____ ZIP CODE: _____

REF	QTY	PART #	DESCRIPTION	UNIT PRICE	TOTAL AMOUNT
H1	16	RPHT12-H1	Leg Bolt (ea.)	.25	
H2	16	RPHT12-H2	Leg Washer (ea.)	.25	
H3	8	RPHT12-H3	1/2" Screw (ea.)	.50	
H4	10	RPHT12-H4	Thumb Screw (ea.)	2.50	
H5	6	RPHT12-H5	Wrench (ea.)	1.00	
A1	4	RPHT12-A1	Small Pusher (ea.)	5.00	
A2	2	RPHT12-A2	Pusher Felt (ea.)	2.00	
A3	1	RPHT12-A3	Small Puck (ea.)	1.00	
P2	2	RPHT12-P2	Left Leg (ea.)	10.00	
P3	2	RPHT12-P3	Right Leg (ea.)	10.00	
P4	2	RPHT12-P4	Crossbar (ea.)	9.00	
P5	2	RPHT12-P5	Goal (ea.)	15.00	
P6	1	RPHT12-P6	Blind Post (ea.)	10.00	
P7	1	RPHT12-P7	Extreme Blin (ea.)	25.00	
	1	RPHT12-MOTOR	Motor (ea.)	25.00	
Up to \$15.00, add \$2.00 for S&H			PA Residents Add 6% State Sales Tax:		
Over \$15.00, add \$8.00 for S&H			Shipping and Handling Charges:		
Console, add \$5.00 for S&H			TOTAL:		

DMI Sports

For Customer Service Call: 1.800.399.4402

PARTS RE-ORDER PAYMENT FORM



Method of Payment

Check or money order ☐ Credit Card ☐ VISA ☐ MasterCard ☐ AMEX ☐ Discover ☐

Credit Card Information

Name (as it appears on card)

Billing Address

City

State

Zip

Shipping Address (if different)

City

State

Zip

Credit Card Type

Expiration Date

Credit Card Number

Send this form along with your check or money order payable to:

DMI SPORTS Inc. 1300 Virginia Dr • Suite 401 • Fort Washington, PA 19034 • www.dmisports.com